

# LV switch-disconnectors

Catalogue

## Interpact Merlin Gerin 40 to 2500 A



**Merlin Gerin**

**Modicon**

**Square D**

**Telemecanique**

**Schneider**  
**Electric**  
We do more with electricity




# LV switch-disconnectors


---


<b>The various low-voltage applications</b>	<b>2</b>
<b>Interpact from 40 to 2500 A</b>	<b>4</b>
<b>Compact from 80 to 1250 A</b>	<b>5</b>
<b>Masterpact from 800 to 6300 A</b>	<b>6</b>
<i>Presentation</i>	7
<i>Functions and characteristics</i>	15
<i>Installation and connection</i>	45
<i>Technical details</i>	69
<i>Catalogue numbers</i>	75

# The various low-voltage applications




## Legend





Masterbloc main power distribution board with Masterpact switch-disconnectors



Prisma sub-distribution board with Interpact switch-disconnectors



Pragma final distribution board with Interpact switch-disconnector

### Source coupling switch-disconnector

- Merlin Gerin Masterpact, Compact CM and Interpact IN switch-disconnectors
- current ratings: up to 6300 A
- standards: IEC 60947-3, EN 60947-3
- catalogue: Masterpact, Compact CM, Interpact (see following pages).

### Main power distribution boards for commercial and industrial applications

- Merlin Gerin Masterpact, Interpact INS/IN and Compact C switch-disconnectors
- current ratings: 400 to 1000 A for commercial applications and 400 to 1600 A for industrial applications
- standards: IEC 60947-3, EN 60947-3
- catalogue: Masterpact, Compact, Interpact (see following pages).

### Industrial switchboards and automatic-control panels

- Merlin Gerin Interpact INS and Compact NS switch-disconnectors
- current ratings: up to 400 A
- standards: IEC 60947-3, EN 60947-3
- catalogue: Compact, Interpact (see following pages).

### Sub-distribution boards for modular products

- Merlin Gerin Interpact INS and NG 125 switch-disconnectors
- current ratings: up to 160 A
- standards: IEC 60947-3, EN 60947-3
- catalogue: Multi 9, Interpact (see following pages).

### Local isolation enclosures

- Merlin Gerin switch-disconnectors:
- Interpact INS and Multi 9 (low ratings)
- Interpact INS and Compact NS
- Telemecanique switch-disconnectors (12 to 175 A)
- current ratings: up to 63 A (low ratings), up to 630 A (industry)
- standards: IEC 60947-3, EN 60947-3
- catalogue: Compact, Interpact (see following pages), Telemecanique.

### Small distribution enclosures for commercial applications

- Merlin Gerin Interpact INS and Multi 9 switch-disconnectors
- current ratings: up to 63 A
- standards: IEC 60947-3, EN 60947-3 or IEC 60669-1
- catalogue: Multi 9, Interpact (see following pages).

### Control panels

- Telemecanique Vario switch-disconnectors
- current ratings: up to 60/80 A
- standards: IEC 60947-3, EN 60947-3
- catalogue: Telemecanique.

### Local isolation enclosures (manufacturing processes and individual machines)

- Interpact INS and Telemecanique Vario switch-disconnectors
- current ratings: up to 63/80 A (Vario) and > 63/80 A (Interpact INS)
- standards: IEC 60947-3, EN 60947-3
- catalogue: Interpact (see following pages), Telemecanique.

- circuit control and isolation
- industrial devices with modular profile from 40 to 160 A
- industrial devices from 100 to 2500 A for installation in functional and universal switchboards
- front or lateral handle are available on the same device (up to INS250)

**Interpact INS from 40 to 630 A***Interpact INS switch-disconnector from 40 to 80 A**Interpact INS switch-disconnector from 100 to 160 A**Interpact INS250 switch-disconnector**Interpact INS switch-disconnector from 400 to 630 A***Interpact IN from 1000 to 2500 A***Interpact IN1600 switch-disconnector*

# Compact from 80 to 1250 A

## See Compact catalogue

- circuit control and isolation
- additional functions for safety, remote control and convenience:
  - earth-fault protection
  - MN/MX auxiliary releases
  - motor mechanism
  - ammeter
  - source changeover
- homogeneity with respect to Compact circuit breakers in the same switchboard



Compact switch-disconnector



Compact switch-disconnector equipped with Vigi earth fault protection module




Compact switch-disconnector with motor-mechanism



MN/MX voltage release

- *circuit control and isolation*
- *high making capacity and electrodynamic withstand*
- *additional functions for safety and convenience:*
  - *MN/MX auxiliary releases*
  - *XF closing release*
  - *motor mechanism*
  - *source changeover*



*Masterpact switch-disconnector*

# Presentation

---

## *LV switch-disconnectors*

<b>Interpact 40 to 2500 A</b>	<b>8</b>
<b>Interpact INS range</b>	<b>10</b>
Simplified installation	10
Enhanced modularity	11
For all fields of activity and all applications	12
Compliance with regulations	13
<i>Functions and characteristics</i>	<i>15</i>
<i>Installation and connection</i>	<i>45</i>
<i>Technical details</i>	<i>69</i>
<i>Catalogue numbers</i>	<i>75</i>

*Interpact 40 to 2500 A switch-disconnectors are used to control and isolate electrical distribution circuits.*



E26903

Interpact switch-disconnectors are used as incomers for:

- source coupling switchboards
- main power distribution switchboards for commercial and industrial applications
- modular distribution switchboards for commercial and industrial applications
- control panels
- enclosures for local control and isolation of circuits supplying motors, machine-tools, etc.



#### Characteristics:

- industrial performance levels as defined by IEC 60947-1 and IEC 60947-3:
- rated operational voltage 500 to 690 V
- rated operational current AC21A, AC22A, AC23A and B, DC21A, DC22A, DC23A and B
- rated impulse-withstand voltage 8 kV
- no derating up to 60° C ambient temperature.
- front or lateral rotary handle
- positive contact indication
- visible break.

### Interpact INS/INV: a complete range from 40 to 630 A



#### Interpact INS

Switch-disconnector  
with positive contact  
indication






#### Interpact INV

Switch-disconnector  
with visible break





#### Interpact INS

Emergency-off switch-disconnector  
with positive contact  
indication



#### Interpact INV


Emergency-off switch-disconnector  
with visible break



#### The complete range

	40 A	63 A	80 A	100 A	125 A	160 A	200 A	250 A	320 A	400 A	500 A	630 A
■ modular profile	INS40	INS63	INS80	INS100	INS125	INS160						
■ mounting on backplate				INS250 100 A	-	INS250 160 A	INS250 200 A	INS250	INS320	INS400	INS500	INS630

### Interpact IN: 1000, 1600 and 2500 A




## Positive contact indication or visible break...



### Positive contact indication




A mechanical device ensures that the position of the handle always reflects the position of the main contacts. With positive contact indication, Schneider guarantees users of the Interpact range an optimum level of safety. When the device is locked in the open position, the user can rest assured that the load circuit is totally isolated from the upstream circuit.



### Visible break

The physical separation of the main contacts is directly visible through a transparent cover. The Interpact INV range thus offers double safety, i.e. both positive contact indication and visible break.


## ...for a wide range of applications



*Interpact INS switch-disconnectors offer the following features:*

- *mounting on a symmetrical rail (up to INS 160) or a backplate*
- *same volume for three and four-pole versions*
- *45 mm-standard front (up to INS 160), as for Multi 9 products*
- *all types of connection made easy*
- *standard rotary handle may be installed on front or side (up to INS 250) (extension option available)*
- *locking of the toggle in the OFF position with up to three padlocks (ON position locking also possible)*
- *remote indications via auxiliary contacts*
- *uniformity with Compact NS range of circuit breakers in terms of frame sizes, aesthetics, auxiliaries, etc.*

### Mounting on a symmetrical rail or a backplate



Mounting on a symmetrical rail (up to INS 160)

Mounting on a symmetrical rail or a backplate

### Simplified connections

#### INS40 to INS80



Connection of bare cables up to 50 mm<sup>2</sup>

#### INS100 to INS160



Standard connection of bars or cables with lugs

### Connection accessories




Distribloc distribution block

- a solution for all installations:
  - 1-cable connectors for Interpact INS 100 to 160
  - distribution connectors for Interpact INS40 to INS80
  - distribution connectors for Interpact INS 100 to 160
  - distribution block, etc.

### New


### One-piece spreader for Interpact INS and INV and Compact NS




One-piece spreader for Interpact INS and INV and Compact NS. Interpact INS and INV and Compact NS devices may be equipped with a spreader corresponding to the pitch of the terminals of the next highest frame size. The one-piece spreader offers improved accessibility and helps conserve the homogeneity of the electrical installation. It may be fitted with all the connection and isolation accessories of the Compact NS device with the next highest frame size.

# Enhanced modularity

## Common accessories with Compact NS circuit breakers




## One catalogue number for auxiliary contacts



A single catalogue number (identical to Compact NS) for auxiliary contacts:

- used on all Interpact INS and INV switch-disconnectors
- no increase in overall volume
- three different functions:
  - OF contact (circuits open/closed)
  - CAF early-make contact
  - CAO early-break contact.

## Front and lateral rotary handle as standard, up to INS 250



The same handle may be easily installed on the front or side with a single screw up to INS160.

Interpact INS 80 with adaptable handle

## Interpact INS range

### For all fields of activity and all applications

*Interpact INS and INV switch-disconnectors integrate perfectly in the Schneider functional system.*

*That guarantees a high level of performance, even under the most severe operating conditions. Whether installed on a symmetrical rail (40 to 160 A) or a back plate (100 to 630 A), Interpact INS and INV switch-disconnectors comply with CNOMO regulations governing machine-tools.*

#### Commercial and industrial applications

Incomers for distribution switchboards in commercial buildings




Sub-distribution boards with Interpact incomers from 40 to 160 A




Power distribution boards with Interpact incomers from 400 to 2500 A

#### Local control of machines



Enclosures for local isolation with Interpact switch-disconnectors from 40 to 630 A



Control panels with Interpact incomers from 63 to 400 A

#### Automatic control panels

#### Manual source-changeover systems

New




The new range of Interpact INS and INV switch-disconnectors offers a complete range of source-changeover solutions with rotary handles, keylocks and, above all, the new complete source changeover assembly with a fast coupling system. All source-changeover systems now have the same distance between centres for mounting to simplify integration in the various installation systems.

# Compliance with regulations

*Interpact INS and INV switch-disconnectors comply with the most recent environmental protection regulations.*

- *Interpact INS and INV switch-disconnectors are modular in design*
- *complete disassembly results in single-material parts, most of which are non-polluting and/or recyclable*
- *moulded parts are made of thermoplastics (PBT, PET, etc.). These materials are made of carbon, hydrogen and oxygen, so their elimination, even by incineration, does not produce any polluting substances.*

## Recyclable materials



## Recyclable packing



## Compliance with all international standards

- The entire range has been fully certified IEC 60947-1, IEC 60947-3 and EN 60947-1, EN 60947-3. Certification was carried out within the framework of the LOVAG agreement by independent certification organizations.
- Marine certification is underway.
- Certain ratings are UL 1087 listed for the markets requiring such certification.






# Functions and characteristics

---

<i>LV switch-disconnectors</i>	1
<i>Presentation</i>	7
<b>General characteristics</b>	<b>16</b>
<b>Switch-disconnector selection</b>	<b>18</b>
Interpact INS40 to 160	18
Interpact INS250	20
Interpact INS320 to 630	22
Interpact INV100 to 250	24
Interpact INV320 to 630	26
Interpact IN1000 to 2500	28
<b>Installation</b>	<b>30</b>
<b>Connection</b>	<b>31</b>
Interpact INS40 to 160	31
Interpact INS250 to 630	32
Interpact INV100 to 630	32
Interpact IN1000 to 2500	34
<b>Connection accessories</b>	<b>35</b>
Distribution blocks	35
One-piece spreader	36
Insulation of live parts	37
<b>Auxiliary contacts</b>	<b>38</b>
<b>Rotary handle</b>	<b>39</b>
<b>Disabling device closing</b>	<b>40</b>
<b>Switching to a replacement source</b>	<b>41</b>
<b>Current measurements</b>	<b>42</b>
<b>Accessories</b>	<b>43</b>
<i>Installation and connection</i>	45
<i>Technical details</i>	69
<i>Catalogue numbers</i>	75

E49309



## Conformity with standards

Interpact switch-disconnectors and auxiliaries comply with the following international recommendations:

- IEC 60947-1: general rules
- IEC 60947-3: switches, disconnectors, switch-disconnectors, etc.
- IEC 60947-5.1 and following: control-circuit devices and switching elements; automatic-control components.

In that these recommendations are applied in most countries, Interpact switch-disconnectors and auxiliaries comply with European (EN 60947-1, EN 60947-3, EN 60947-5-1) and the corresponding national standards:

- France NF
- Germany VDE
- United Kingdom BS
- Australia AS
- Italy CEI.

Interpact switch-disconnectors are suitable for the control of machine-tools in that they comply with French standard NF C 79-130 and with the recommendations issued by the CNOMO organisation.

## Class II front face

This insulation is obtained by:

- double insulation for the INS range
- respecting the distances and insulation rules defined in standards IEC 60661, IEC 60947-1, IEC 60364... For the INV range.

## Tropicalisation

Interpact switch-disconnectors meet the tropicalisation T2 requirements as defined in the following standards:

- IEC 68-2-30: 95% relative humidity at  $55^\circ\text{C}$  (hot and humid climate conditions)
- IEC 68-2-11: salt mist.

## Degree of pollution


Interpact switch-disconnectors are certified for operation in pollution-degree III environments as defined by IEC standard 60947 (industrial environments).

## Ambient temperature

- Interpact switch-disconnectors can be used at temperatures ranging from  $-25^\circ\text{C}$  to  $70^\circ\text{C}$ . Above  $60^\circ\text{C}$ , always take into account the derating coefficients indicated in the documentation
- wherever possible, the switch-disconnectors should be put into service at their normal ambient operating temperature, however this can be done at temperatures between  $-35^\circ\text{C}$  and  $-25^\circ\text{C}$  as long as this condition does not last for an extended period
- in their original packing, Interpact switch-disconnectors may be stored at temperatures ranging from  $-50^\circ\text{C}$  to  $+85^\circ\text{C}$ .


## Degree of protection (as per standard NF C 20-010)

IP40




Bare switch-disconnector with terminal shields

IP40




Switch-disconnector in cabinet or enclosure (direct handle)


IP55




Switch-disconnector in cabinet or enclosure (extended handle)




Suitable for isolation with positive contact indication



Suitable for isolation with visible break



INS250 emergency-off switch-disconnector



INV250 emergency-off switch-disconnector

### Suitable for isolation with positive contact indication



All Interpact switch-disconnectors are suitable for isolation as defined in IEC standard 60947-3:

- the isolation position corresponds to the O (OFF) position
- the operating handle cannot indicate the OFF position unless the contacts are actually open
- padlocking in the OFF position is not possible unless the contacts are actually open.

Installation of an extended handle does not alter the suitability for isolation. The isolation function is certified by tests guaranteeing:

- the mechanical reliability of the position-indication system
- the absence of leakage currents
- overvoltage withstand capacity between upstream and downstream connections.

### Suitable for isolation with visible break

The physical separation of the main contacts is directly visible through a transparent cover.

The Interpact INV range offers both positive contact indication and visible break.

### Emergency-off switch disconnector

This switch-disconnector can be used as an emergency-off device. For this application, it must be easily visible, accessible and identifiable (see standards and rules concerning the safety of machines VDE 0660, VDE 0113, CNOMO, etc.).

For easy identification, the emergency-off switch-disconnector uses special colours stipulated by the standards and different from those of the standard version:

- yellow for the front face of the device
- red for the handle.

The performance characteristics of Interpact emergency-off switch-disconnector are the same as those of the standard version.

The emergency-off switch-disconnectors are available in positive contact indication and visible-break versions.

## Switch-disconnector selection


### Interpact INS40 to 160



Interpact INS80 switch-disconnector



Interpact INS160 switch-disconnector



Interpact INS160 emergency-off switch-disconnector

#### Interpact INS switch-disconnectors

##### Number of poles

Electrical characteristics as defined by IEC 60947-1 / IEC 60947-3 and EN 60947-1 / 60947-3

Conventional thermal current (A)	I <sub>th</sub>	at 60 °C
Rated insulation level (V)	U <sub>i</sub>	AC 50/60 Hz
Impulse-withstand voltage (kV)	U <sub>imp</sub>	
Rated operational voltage (V)	U <sub>e</sub>	AC 50/60 Hz DC
Rated operational current (A)	I <sub>e</sub>	<b>AC 50/60 Hz</b> 220-240 V 380-415 V 440-480 V (1) 500 V 660-690 V <b>DC</b> 125 V (2P in series) 250 V (4P in series)
		uninterrupted duty intermittent duty
Short-circuit making capacity	I <sub>cm</sub> (kA peak)	min. (switch-disconnector alone) max. (with upstream protection circuit breaker)
Short-time withstand current	I <sub>cw</sub> (A rms)	1s 3 s 20 s

##### Suitability for isolation

Endurance (category A) (CO cycles)	mechanical electrical AC AC22A 500 V AC22A 690 V AC23A 220-240 V AC23A 380-415 V AC23A 440 V AC23A 500 V AC23A 690 V electrical DC DC23A 250 V
------------------------------------	--

##### Positive contact indication

##### Degree of pollution

##### Upstream protection

See the "Technical details" section, page 4.0000

##### Installation and connection

Fixed, front connection	symmetrical rail backplate
-------------------------	-------------------------------

#### Indication and measurement auxiliaries

##### Auxiliary contacts

##### Voltage-presence indicator

##### Current-transformer module

##### Ammeter module

##### Insulation-monitoring module

#### Control auxiliaries

##### Auxiliary releases and motor mechanism

##### Direct and extended front / lateral rotary handle

##### Locking by padlocks

##### Manual source-changeover system

#### Installation and connection accessories

##### Bare cable connectors

##### Terminal extensions and spreaders

##### Terminal shields and shrouds

##### Phase barriers

##### Front-panel escutcheon

#### Dimensions and weights


Overall dimensions H x W x D (mm)	3/4 poles
Approximate weight (kg)	3 poles
	4 poles

(1) Suitable for 480 V NEMA

INS40		INS63		INS80		INS100		INS125		INS160	
3, 4	3, 4	3, 4	3, 4	3, 4	3, 4	3, 4	3, 4	3, 4	3, 4	3, 4	3, 4
40	63	80	100	125	160						
690	690	690	750	750	750						
8	8	8	8	8	8						
500	500	500	690	690	690						
250	250	250	250	250	250						
AC 22 A	AC 23 A	AC 22 A	AC 23 A	AC 22 A	AC 23 A	AC 22 A	AC 23 A	AC 22 A	AC 23 A	AC 22 A	AC 23 A
40	40	63	63	80	80	100	100	125	125	160	160
40	40	63	63	80	72	100	100	125	125	160	160
40	40	63	63	80	63	100	100	125	125	160	160
40	32	63	40	80	40	100	100	125	125	160	160
-	-	-	-	-	-	100	63	125	80	160	100
DC 22 A	DC 23 A	DC 22 A	DC 23 A	DC 22 A	DC 23 A	DC 22 A	DC 23 A	DC 22 A	DC 23 A	DC 22 A	DC 23 A
40	40	63	63	80	80	100	100	125	125	160	160
40	40	63	63	80	80	100	100	125	125	160	160
■	■	■	■	■	■	■	■	■	■	■	■
class 120 - 60%	class 120 - 60%	class 120 - 60%	class 120 - 60%	class 120 - 60%	class 120 - 60%	class 120 - 60%	class 120 - 60%	class 120 - 60%			
15	15	15	15	20	20	20	20	20	20	20	20
75	75	75	75	154	154	154	154	154	154	154	154
3000	3000	3000	5500	5500	5500	5500	5500	5500	5500	5500	5500
1730	1730	1730	3175	3175	3175	3175	3175	3175	3175	3175	3175
670	670	670	1230	1230	1230	1230	1230	1230	1230	1230	1230
■	■	■	■	■	■	■	■	■	■	■	■
20000	20000	20000	15000	15000	15000	15000	15000	15000	15000	15000	15000
1500	1500	1500	1500	1500	1500	1500	1500	1500	1500	1500	1500
-	-	-	-	1500	1500	1500	1500	1500	1500	1500	1500
1500	1500	1500	1500	1500	1500	1500	1500	1500	1500	1500	1500
1500	1500	1500	1500	1500	1500	1500	1500	1500	1500	1500	1500
1500	1500	1500	1500	1500	1500	1500	1500	1500	1500	1500	1500
-	-	-	-	1500	1500	1500	1500	1500	1500	1500	1500
1500	1500	1500	1500	1500	1500	1500	1500	1500	1500	1500	1500
yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
III	III	III	III	III	III	III	III	III	III	III	III
■	■	■	■	■	■	■	■	■	■	■	■
■	■	■	■	■	■	■	■	■	■	■	■
■	■	■	■	■	■	■	■	■	■	■	■
-	-	-	-	-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-	-	-	-	-
90 x 81 x 62.5	90 x 81 x 62.5	90 x 81 x 62.5	135 x 100 x 62.5	135 x 100 x 62.5	135 x 100 x 62.5	135 x 100 x 62.5	135 x 100 x 62.5	135 x 100 x 62.5	135 x 100 x 62.5	135 x 100 x 62.5	135 x 100 x 62.5
0.5	0.5	0.5	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8
0.6	0.6	0.6	0.9	0.9	0.9	0.9	0.9	0.9	0.9	0.9	0.9

# Switch-disconnector selection

## Interpact INS250



Interpact INS250 switch-disconnector



Interpact INS250 emergency-off switch-disconnector

### Interpact INS switch-disconnectors

#### Number of poles

Electrical characteristics as defined by IEC 60947-1 / IEC 60947-3 and EN 60947-1 / 60947-3

Conventional thermal current (A)	I <sub>th</sub>	at 60 °C
----------------------------------	-----------------	----------

Rated insulation level (V)	U <sub>i</sub>	AC 50/60 Hz
----------------------------	----------------	-------------

Impulse-withstand voltage (kV)	U <sub>imp</sub>	
--------------------------------	------------------	--

Rated operational voltage (V)	U <sub>e</sub>	AC 50/60 Hz DC
-------------------------------	----------------	-------------------

Rated operational current (A)	I <sub>e</sub>	AC	50/60 Hz
-------------------------------	----------------	----	----------

		220-240 V
--	--	-----------

		380-415 V
--	--	-----------

		440-480 V (1)
--	--	---------------

		500-525 V
--	--	-----------

		660-690 V
--	--	-----------

DC		
----	--	--

		125 V (2P in series)
--	--	----------------------

		250 V (4P in series)
--	--	----------------------

#### Rated duties

uninterrupted duty	
--------------------	--

intermittent duty	
-------------------	--

Short-circuit making capacity	I <sub>cm</sub> (kA peak)	min. (switch-disconnector alone) max. (with upstream protection circuit breaker)
-------------------------------	------------------------------	---

Short-time withstand current	I <sub>cw</sub> (A rms)	1s 3 s 20 s 30 s
------------------------------	----------------------------	---------------------------

#### Suitability for isolation

##### Endurance (category A) (CO cycles)

mechanical	AC22A 500 V
electrical AC	AC22A 690 V
	AC23A 440 V
	AC23A 500 V
	AC23A 690 V
electrical DC	DC23A 250 V

#### Positive contact indication

#### Degree of pollution

#### Upstream protection

See the "Technical details" section, page 4.0000

#### Installation and connection

Fixed, front connection

Fixed, rear connection

#### Indication and measurement auxiliaries

##### Auxiliary contacts

##### Voltage-presence indicator

##### Current-transformer module

##### Ammeter module

##### Insulation-monitoring module

#### Control auxiliaries

##### Auxiliary releases and motor mechanism

Direct and extended front rotary handle

Direct and extended lateral rotary handle

Locking by padlocks

Manual source-changeover system

#### Installation and connection accessories

##### Bare cable connectors

##### Terminal extensions, spreaders and one-piece spreader

##### Terminal shields and shrouds

##### Phase barriers

##### Front-panel escutcheon

#### Dimensions and weights

Overall dimensions H x W x D (mm)	3/4 poles
-----------------------------------	-----------

Approximate weight (kg)	3 poles
-------------------------	---------

	4 poles
--	---------

(1) Suitable for 480 V NEMA

(2) Mounted with adaptation kit for direct rotary handle


INS250-100		INS250-160		INS250-200		INS250	
3, 4		3, 4		3, 4		3, 4	
100	160	200	250				
750	750	750	750				
8	8	8	8				
690	690	690	690				
250	250	250	250				
AC 22 A	AC 23 A	AC 22 A	AC 23 A	AC 22 A	AC 23 A	AC 22 A	AC 23 A
100	100	160	160	200	200	250	250
100	100	160	160	200	200	250	250
100	100	160	160	200	200	250	250
100	100	160	160	200	200	250	250
DC 22 A	DC 23 A	DC 22 A	DC 23 A	DC 22 A	DC 23 A	DC 22 A	DC 23 A
100	100	160	160	200	200	250	250
100	100	160	160	200	200	250	250
■	■	■	■	■	■	■	■
class 120 - 60%							
30	30	30	30				
330	330	330	330				
8500	8500	8500	8500				
4900	4900	4900	4900				
2200	2200	2200	2200				
1800	1800	1800	1800				
■	■	■	■				
15000	15000	15000	15000				
1500	1500	1500	1500				
1500	1500	1500	1500				
1500	1500	1500	1500				
1500	1500	1500	1500				
1500	1500	1500	1500				
yes	yes	yes	yes				
III	III	III	III				
■	■	■	■				
■	■	■	■				
■	■	■	■				
■	■	■	■				
■ (2)	■ (2)	■ (2)	■ (2)				
-	-	-	-				
■	■	■	■				
■	■	■	■				
■	■	■	■				
■	■	■	■				
■	■	■	■				
■	■	■	■				
■	■	■	■				
■	■	■	■				
140 x 136 x 86							
2	2	2	2				
2.2	2.2	2.2	2.2				

## Switch-disconnector selection

### Interpact INS320 to 630



Interpact INS400 switch-disconnector



Interpact INS400 emergency-off switch-disconnector

#### Interpact INS switch-disconnectors

##### Number of poles

Electrical characteristics as defined by IEC 60947-1 / IEC 60947-3 and EN 60947-1 / 60947-3

Conventional thermal current (A)	I <sub>th</sub>	at 60 °C	
Rated insulation level (V)	U <sub>i</sub>	AC 50/60 Hz	
Impulse-withstand voltage (kV)	U <sub>imp</sub>		
Rated operational voltage (V)	U <sub>e</sub>	AC 50/60 Hz DC	
Rated operational current (A)	I <sub>e</sub>	AC	50/60 Hz 220-240 V 380-415 V 440-480 V (1) 500-525 V 660-690 V
		DC	125 V (2P in series) 250 V (4P in series)
Rated duties		uninterrupted duty intermittent duty	
Short-circuit making capacity	I <sub>cm</sub> (kA peak)	min. (switch-disconnector alone) max. (with upstream protection circuit breaker)	
Short-time withstand current	I <sub>cw</sub> (A rms)	1s 3 s 20 s 30 s	

##### Suitability for isolation

###### Endurance (category A) (CO cycles)

mechanical	AC22A 500 V
electrical AC	AC22A 690 V
	AC23A 440 V
	AC23A 500 V
	AC23A 690 V
electrical DC	DC23A 250 V

##### Positive contact indication

##### Degree of pollution

###### Upstream protection

See the "Technical details" section, page 4.0000

##### Installation and connection

###### Fixed, front connection

###### Fixed, rear connection

##### Indication and measurement auxiliaries

###### Auxiliary contacts

###### Voltage-presence indicator

###### Current-transformer module

###### Ammeter module

###### Insulation-monitoring module

##### Control auxiliaries

###### Auxiliary releases and motor mechanism

###### Direct and extended front rotary handle

###### Direct and extended lateral rotary handle

###### Locking by padlocks

###### Manual source-changeover system

##### Installation and connection accessories

###### Bare cable connectors

###### Terminal extensions, spreaders and one-piece spreader

###### Terminal shields and shrouds

###### Phase barriers

###### Front-panel escutcheon

##### Dimensions and weights

###### Overall dimensions H x W x D (mm)

3/4 poles

###### Approximate weight (kg)

3 poles

4 poles

(1) Suitable for 480 V NEMA

<b>INS320</b>	<b>INS400</b>	<b>INS500</b>	<b>INS630</b>
3, 4	3, 4	3, 4	3, 4
320	400	500	630
750	750	750	750
8	8	8	8
690	690	690	690
250	250	250	250
<b>AC 22 A</b>	<b>AC 23 A</b>	<b>AC 22 A</b>	<b>AC 23 A</b>
320	320	400	400
320	320	400	400
320	320	400	400
320	320	400	400
320	320	400	400
<b>DC 22 A</b>	<b>DC 23 A</b>	<b>DC 22 A</b>	<b>DC 23 A</b>
320	320	400	400
320	320	400	400
■	■	■	■
class 120 - 60%			
50	50	50	50
330	330	330	330
20000	20000	20000	20000
11500	11500	11500	11500
4900	4900	4900	4900
4000	4000	4000	4000
■	■	■	■
10000	10000	10000	10000
1500	1500	1500	1500
1500	1500	1500	1000
1500	1500	1500	1500
1500	1500	1500	1500
1500	1500	1500	1500
1500	1500	1500	1000
yes	yes	yes	yes
III	III	III	III
■	■	■	■
■	■	■	■
■	■	■	■
■	■	■	■
■	■	■	■
■	■	■	■
-	-	-	-
■	■	■	■
■	■	■	■
■	■	■	■
■	■	■	■
■	■	■	■
185 x 205 x 120			
4.6	4.6	4.6	4.6
4.9	4.9	4.9	4.9



Interpact INV250 switch-disconnector



Interpact INS250 emergency-off switch-disconnector

## Switch-disconnector selection

### Interpact INV100 to 250 with visible break

#### Interpact INV switch-disconnectors

##### Number of poles

Electrical characteristics as defined by IEC 60947-1 / IEC 60947-3 and EN 60947-1 / 60947-3

Conventional thermal current (A)	I <sub>th</sub>	at 60 °C	
Rated insulation level (V)	U <sub>i</sub>	AC 50/60 Hz	
Impulse-withstand voltage (kV)	U <sub>imp</sub>		
Rated operational voltage (V)	U <sub>e</sub>	AC 50/60 Hz DC	
Rated operational current (A)	I <sub>e</sub>	AC	50/60 Hz 220-240 V 380-415 V 440-480 V (1) 500-525 V 660-690 V
		DC	125 V (2P in series) 250 V (4P in series)
Rated duties		uninterrupted duty intermittent duty	
Short-circuit making capacity	I <sub>cm</sub> (kA peak)	min. (switch-disconnector alone) max. (with upstream protection circuit breaker)	
Short-time withstand current	I <sub>cw</sub> (A rms)	1s	
		3 s	
		20 s	
		30 s	
Suitability for isolation			
Endurance (category A) (CO cycles)		mechanical	
		electrical AC	AC21A 690 V AC22A 500 V AC22A 690 V AC23B 440 V AC23B 500 V AC23B 690 V
		electrical DC	DC22A 250 V DC23B 250 V

##### Positive contact indication

##### Degree of pollution

##### Upstream protection

See the "Technical details" section, page 4.0000

##### Installation and connection

##### Fixed, front connection

##### Fixed, rear connection

##### Indication and measurement auxiliaries

##### Auxiliary contacts

##### Voltage-presence indicator

##### Current-transformer module

##### Ammeter module

##### Insulation-monitoring module

##### Control auxiliaries

##### Auxiliary releases and motor mechanism

##### Direct and extended front rotary handle

##### Direct and extended lateral rotary handle

##### Locking by padlocks

##### Manual source-changeover system

##### Installation and connection accessories

##### Bare cable connectors

##### Terminal extensions, spreaders and one-piece spreader

##### Terminal shields and shrouds

##### Phase barriers

##### Front-panel escutcheon

##### Dimensions and weights

##### Overall dimensions H x W x D (mm)

3/4 poles

##### Approximate weight (kg)

3 poles

4 poles

(1) Suitable for 480 V NEMA

(2) Montage avec kit d'adaptation pour commande rotative directe

INV100			INV160			INV200			INV250		
3, 4			3, 4			3, 4			3, 4		
100			160			200			250		
750			750			750			750		
8			8			8			8		
690			690			690			690		
250			250			250			250		
AC21A			AC22A			AC23B			AC21A		
100	100	100	160	160	160	200	200	200	250	250	250
100	100	100	160	160	160	200	200	200	250	250	250
100	100	100	160	160	160	200	200	200	250	250	250
100	100	80	160	160	80	200	200	100	250	250	100
100	-	-	160	-	-	200	-	-	250	-	-
DC21A	DC22A	DC23B									
100	100	100	160	160	160	200	200	200	250	250	200
100	100	100	160	160	160	200	200	200	250	250	200
■	■	■	■	■	■	■	■	■	■	■	■
class 120 - 60%			class 120 - 60%			class 120 - 60%			class 120 - 60%		
30	30	30	30	30	30	30	30	30	30	30	30
330	330	330	330	330	330	330	330	330	330	330	330
8500	8500	8500	8500	8500	8500	8500	8500	8500	8500	8500	8500
4900	4900	4900	4900	4900	4900	4900	4900	4900	4900	4900	4900
2200	2200	2200	2200	2200	2200	2200	2200	2200	2200	2200	2200
1800	1800	1800	1800	1800	1800	1800	1800	1800	1800	1800	1800
■	■	■	■	■	■	■	■	■	■	■	■
15000	15000	15000	15000	15000	15000	15000	15000	15000	15000	15000	15000
1500	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000
1500	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000
-	-	-	-	-	-	-	-	-	-	-	-
300	200	200	200	200	200	200	200	200	200	200	200
300	200	200	200	200	200	200	200	200	200	200	200
-	-	-	-	-	-	-	-	-	-	-	-
1500	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000
300	200	200	200	200	200	200	200	200	200	200	200
yes	yes	yes									
III	III	III									
■	■	■	■	■	■	■	■	■	■	■	■
■	■	■	■	■	■	■	■	■	■	■	■
■	■	■	■	■	■	■	■	■	■	■	■
■	■	■	■	■	■	■	■	■	■	■	■
■ (2)	■ (2)	■ (2)	■ (2)	■ (2)	■ (2)	■ (2)	■ (2)	■ (2)	■ (2)	■ (2)	■ (2)
-	-	-	-	-	-	-	-	-	-	-	-
■	■	■	■	■	■	■	■	■	■	■	■
■	■	■	■	■	■	■	■	■	■	■	■
■	■	■	■	■	■	■	■	■	■	■	■
■	■	■	■	■	■	■	■	■	■	■	■
■	■	■	■	■	■	■	■	■	■	■	■
■	■	■	■	■	■	■	■	■	■	■	■
140 x 136 x 86	140 x 136 x 86	140 x 136 x 86	140 x 136 x 86	140 x 136 x 86	140 x 136 x 86	140 x 136 x 86	140 x 136 x 86	140 x 136 x 86	140 x 136 x 86	140 x 136 x 86	140 x 136 x 86
2	2	2	2	2	2	2	2	2	2	2	2
2.2	2.2	2.2	2.2	2.2	2.2	2.2	2.2	2.2	2.2	2.2	2.2

## Switch-disconnector selection

### Interpact INV320 to 630 with visible break



Interpact INV630 switch-disconnector



Interpact INV630 emergency-off switch-disconnector

#### Interpact INV switch-disconnectors

##### Number of poles

Electrical characteristics as defined by IEC 60947-1 / IEC 60947-3 and EN 60947-1 / 60947-3

Conventional thermal current (A)	I <sub>th</sub>	at 60 °C	
Rated insulation level (V)	U <sub>i</sub>	AC 50/60 Hz	
Impulse-withstand voltage (kV)	U <sub>imp</sub>		
Rated operational voltage (V)	U <sub>e</sub>	AC 50/60 Hz DC	
Rated operational current (A)	I <sub>e</sub>	AC	50/60 Hz 220-240 V 380-415 V 440-480 V (1) 500-525 V 660-690 V
		DC	125 V (2P in series) 250 V (4P in series)
Rated duties		uninterrupted duty intermittent duty	
Short-circuit making capacity	I <sub>cm</sub> (kA peak)	min. (switch-disconnector alone) max. (with upstream protection circuit breaker)	
Short-time withstand current	I <sub>cw</sub> (A rms)	1s	
		3 s	
		20 s	
		30 s	

##### Suitability for isolation

###### Endurance (category A) (CO cycles)

mechanical	
electrical AC	AC21A 690 V
	AC22A 500 V
	AC22A 690 V
	AC23B 440 V
	AC23B 500 V
	AC23B 690 V
electrical DC	DC22A 250 V
	DC23B 250 V

##### Positive contact indication

###### Degree of pollution

###### Upstream protection

See the "Technical details" section, page 4.0000

##### Installation and connection

###### Fixed, front connection

###### Fixed, rear connection

##### Indication and measurement auxiliaries

###### Auxiliary contacts

###### Voltage-presence indicator

###### Current-transformer module

###### Ammeter module

###### Insulation-monitoring module

##### Control auxiliaries

###### Auxiliary releases and motor mechanism

###### Direct and extended front rotary handle

###### Direct and extended lateral rotary handle

###### Locking by padlocks

###### Manual source-changeover system

##### Installation and connection accessories

###### Bare cable connectors

###### Terminal extensions, spreaders and one-piece spreader

###### Terminal shields and shrouds

###### Phase barriers

###### Front-panel escutcheon

##### Dimensions and weights

###### Overall dimensions H x W x D (mm)

3/4 poles

###### Approximate weight (kg)

3 poles

4 poles

(1) Suitable for 480 V NEMA



# Switch-disconnector selection

## Interpact IN1000 to 2500



Interpact IN1000 switch-disconnector

### Interpact IN switch-disconnectors

#### Number of poles

Electrical characteristics as defined by IEC 60947-1 / IEC 60947-3 and EN 60947-1 / 60947-3

Conventional thermal current (A)	I <sub>th</sub>	at 60 °C
----------------------------------	-----------------	----------

Rated insulation level (V)	U <sub>i</sub>	AC 50/60 Hz
----------------------------	----------------	-------------

Impulse-withstand voltage (kV)	U <sub>imp</sub>	
--------------------------------	------------------	--

Rated operational voltage (V)	U <sub>e</sub>	AC 50/60 Hz CC
-------------------------------	----------------	-------------------

Rated operational current (A)	I <sub>e</sub>	<b>AC 50/60 Hz</b>
-------------------------------	----------------	--------------------

220-240 V	
380-415 V	
440-480 V (1)	
500 V	
660-690 V	

#### DC

125 V (2P)	
250 V (4P)	

Short-circuit making capacity	I <sub>cm</sub> (kA peak)	min. (switch-disconnector alone) max. (with upstream protection circuit breaker)
-------------------------------	---------------------------	---

Short-time withstand current	I <sub>cw</sub> (A rms)	1s
------------------------------	-------------------------	----

3 s	
-----	--

20 s	
------	--

#### Suitability for isolation

Endurance (category A) (CO cycles)	mechanical
------------------------------------	------------

electrical AC	AC22A 500 V
	AC22A 690 V
	AC23A 440 V
	AC23A 500 V

electrical DC	DC23A 250 V
	DC23A 500 V

#### Positive contact indication

#### Degree of pollution

#### Upstream protection

See the "Technical details" section, page 4.0000

#### Installation and connection

Fixed, front connection	symmetrical rail
-------------------------	------------------

	backplate
--	-----------

#### Indication and measurement auxiliaries

##### Auxiliary contacts

Voltage-presence indicator	
----------------------------	--

Current-transformer module	
----------------------------	--

Ammeter module	
----------------	--

Insulation-monitoring module	
------------------------------	--

##### Control auxiliaries

Auxiliary releases	
--------------------	--

Motor mechanism	
-----------------	--

Direct and extended front rotary handle	
---	--

Direct and extended lateral rotary handle	
---	--

Locking by padlocks	
---------------------	--

Manual source-changeover system	
---------------------------------	--

#### Installation and connection accessories

Bare cable connectors	
-----------------------	--

Terminal extensions and spreaders	
-----------------------------------	--

Terminal shields and phase barriers	
-------------------------------------	--

Front-panel escutcheon	
------------------------	--

#### Dimensions and weights

Overall dimensions H x W x D (mm)	3 poles fixed, front connection
-----------------------------------	---------------------------------

4 poles fixed, front connection	
---------------------------------	--

Approximate weight (kg)	3 poles fixed, front connection
-------------------------	---------------------------------

4 poles fixed, front connection	
---------------------------------	--

(1) Suitable for 480 V NEMA

(2) IN1000: 630 A for AC23A,  
IN1600: 800 A for AC23A.

(3) 1450 A at 60° C

IN1000	IN1600	IN2500
3, 4	3, 4	3, 4
1000	1600 (at 50° C) (3)	2500
690	690	690
8	8	8
690	690	690
250	250	250
AC 21 A	AC 22 A	AC 21 A
1000	1000	1600
1000	1000 (2)	1600
1000	800	1200
1000	800	1200
1000	-	1600
DC 22 A	DC 23 A	DC 22 A
1000	1000	1600
1000	1000	1600
75		75
176		105
35000	35000	50000
20000	20000	28500
7800	7800	11000
■	■	■
3000	3000	3000
500	500	500
500	500	500
-	-	-
-	-	-
500	500	500 (DC21A)
-	-	-
yes	yes	yes
III	III	III
-	-	-
■	■	■
■	■	■
-	-	-
-	-	-
-	-	-
-	-	-
-	-	-
-	-	-
-	-	-
■	■	■
■	■	■
■	■	■
■	■	■
-	-	-
340 x 300 x 118	340 x 300 x 118	340 x 440 x 200
410 x 300 x 118	410 x 300 x 118	410 x 440 x 200
12	15	35
15	18	45



Local isolation enclosure



Power distribution incomer in a Prisma cubicle




Power distribution incomer in a Prisma GK cubicle

Interpact INS and INV switch-disconnectors offer a number of rational installation solutions to optimise available space inside enclosures. They may be installed in individual enclosures or as incomers in power distribution or control panels.

- Interpact INS40 to 160 switch-disconnectors have a standard 45 mm high front and may be clipped onto a Multifix or symmetrical rail. They may be installed in all Multi 9 modular enclosures, including Pragma, Prisma, etc.
- Interpact INS250 to 630 and INV100 to 630 switch-disconnectors may be installed on mounting plates or rails. Installation as incomers in Prisma power distribution cubicles is very flexible:
  - the mounting plates are the same as those used for Compact NS circuit breakers and are identical for direct and extended handles
  - installation in 300 mm ducts is possible for ratings up to 630 A.
- Interpact IN1000 to 2500 switch-disconnectors may be installed on backplates or rails.

### Individual enclosures


- each individual enclosure includes:
    - a door with a cut-out
    - a mounting plate
    - accessories required for extended front or lateral rotary handle
    - removable plates (without holes) for cable entry.
- The Interpact INS switch-disconnector must be ordered separately.



Heavy-duty individual enclosure (sheet metal or plastic)

### Pragma modular enclosures


- the enclosures in the Pragma range are:
  - made of self-extinguishing insulating material
  - supplied with all accessories (terminal blocks, blanking plates, etc.)
  - rated class 2.



Interpact INS40 on a symmetrical rail

### Prisma metal cubicles and enclosures

- the metal cubicles and enclosures in the Prisma range are highly adaptable to the type of installation:
  - basic cubicle or enclosure
  - multifix rail
  - modular front plates
  - distribution accessories
  - ducts for running cables or installing terminals
  - plain or transparent doors.




Installation in a 300 mm duct


# Connection

## Interpact INS40 to 160

E54455



E39883



### Interpact INS40 to INS80


Interpact INS40 to INS80 switch-disconnectors are equipped as standard with connectors for bare copper or aluminium cables.

#### Distribution connector


This connector screws directly into the switch-disconnector terminals for connection of three cables of the following types:

- 1 to 10 mm<sup>2</sup> flexible cables
- 1.5 to 16 mm<sup>2</sup> rigid cables
- with crimped or auto-crimping ferrules from 1.5 to 4 mm<sup>2</sup>.


E39432



E54456



E39889



### Interpact INS100 to INS160

#### Connection of bars or cables with lugs

Interpact INS100 to INS160 switch-disconnectors are equipped as standard with terminals comprising nuts with M6 screws for direct connection of insulated bars or cables with lugs.

#### Lugs

The special lugs for copper cables may be used for cables with cross-sectional areas up to 95 mm<sup>2</sup>.


Crimping by hexagonal necking or punching. Lugs are supplied with phase barriers and are compatible with the terminal shields.

E54463




Lug for copper cable

E54457



E32423



#### Connection of bare cables (Cu or Al)


- 1-cable connectors for Interpact INS100/125/160 snap directly onto the terminals
- distribution connectors are designed for four cables with a cross-section areas of 1.5 to 25 mm<sup>2</sup> rigid / 16 mm<sup>2</sup> flexible. They screw directly to the terminals. The phase barriers supplied with the distribution connectors may be replaced by long terminal shields.

E2424



1-cable connector

E30707








Distribution connector

# Connection

## Interpact INS250 to 630

## Interpact INV100 to 630

E54456



### Front connection of bars or cables with lugs

Interpact INS250 to INS630 and INV100 to INV630 switch-disconnectors are equipped as standard with terminals receiving snap-in nuts and screws (M8 for INS/INV up to 250, M10 from 320 upwards) for direct connection of insulated bars or cables with lugs. Terminal extensions (right-angle, edgewise, spreaders) are available to solve all connection problems. For Interpact INS/INV630 switch-disconnectors, connection most often requires the 52.5 or 70 mm pitch spreaders.


#### Lugs

Lugs are different for copper and aluminium cables. They are supplied with phase barriers and are compatible with the long terminal shields.


- the small lugs for copper cables may be used for cables with the following cross-sectional areas:
  - 120, 150 or 185 mm<sup>2</sup> (INS/INV up to 250)
  - 240 or 300 mm<sup>2</sup> (INS/INV up to 630).
 Crimping by hexagonal necking or punching.
- the small lugs for aluminium cables may be used for cables with the following cross-sectional areas:
  - 150 or 185 mm<sup>2</sup> (INS/INV up to 250)
  - 240 or 300 mm<sup>2</sup> (INS/INV up to 630).
 Crimping by hexagonal necking.

#### Spreaders


Spreaders increase the pitch of the terminals. They are not compatible with terminal shields. The one-piece spreader increases the pitch to correspond to that of the upstream device and provides protection against direct contact (see page 2.0060).




Right-angle terminal extensions




Straight terminal extensions for INS/INV250




Edgewise terminal extensions for INS/INV320 to 630




Lug for copper cables





Lug for aluminium cables



Spreaders



One-piece spreader




### Front connection of bare cables

Bare-cable connectors for Interpact INS/INV switch-disconnectors may be used for both copper and aluminium cables.

#### 1-cable connectors for Interpact INS250 and INV100 to 250


The connectors snap directly on to the device terminals or clip onto right-angle and straight terminal extensions as well as spreaders.




1-cable connector for  
INS250 and INV100-250



1-cable connector  
for INS/INV320 to 630



2-cable connector  
for INS/INV320 to 630



Distribution connector for  
INS250 and INV100 to 250

#### 1-cable and 2-cable connectors for Interpact INS/INV320 to 630


The connectors are screwed to device terminals or right-angle terminal extensions.

#### Distribution connectors for Interpact INS250 and INV100 to 250



These connectors are screwed directly to device terminals. Phase barriers are supplied with distribution connectors, but may be replaced by long terminal shields. Each connector can receive six cables with cross-sectional areas ranging from 1.5 to 35 mm<sup>2</sup> each.

#### Polybloc distribution block for Interpact INS250 and INV100 to 250

The Polybloc connects directly to the device terminals and is used to connect up to six or nine flexible or rigid cables with cross-sectional areas not exceeding 10 mm<sup>2</sup>, to each pole. Connection is made to spring terminals without screws.




Polybloc distribution block for  
INS250 and INV100 to 250




### Rear connection

Rear connections for bars or cables with lugs are available in two lengths. Bars may be positioned flat, on edge or at 45° angles depending on how the rear connections are positioned. The rear connections are simply fitted to the device connection terminals. All combinations of rear connection lengths and positions are possible on a given switch-disconnector. The switch-disconnector is mounted on a backplate. For the connection of cables without lugs, the 1-cable connectors for Interpact INS250 and INV100 to 250 may be simply clipped onto the rear connections.




Two lengths




Four positions.

E94440




### Direct connection

#### Bars




### Connection with accessories


#### Spreaders



#### Edgewise terminal connections



#### Connectors



IN2500

# Connection accessories


## Distribution blocks

053997




Distribloc 125 A

EB4475



### Distribloc



Distribloc is a four-pole distribution block offering:

- 13 outgoing terminals per phase (12 spring terminals and 1 tunnel terminal)
- 1 incoming tunnel terminal for 35 mm<sup>2</sup> flexible cable (50 mm<sup>2</sup> rigid).

Distribloc exists in two versions:

- Distribloc 125, for switch-disconnectors rated up to 125 A
- Distribloc 160, supplied with prefabricated connections, for direct connection to switch-disconnectors INS100 to INS160.

Distribloc is supplied with a modular cover that fulfils a number of functions:

- circuit identification: a protected label identifies the various circuits
- aesthetics: the cover has the same design as the associated Interpact INS switch-disconnector

- user information: all required information is indicated on the cover.


Distribloc can be installed:

- on a symmetrical rail or a backplate
- to the left, the right or under the switch-disconnector, depending on the desired layout of the switchboard. Installation to the left is particularly useful when the INS switch-disconnector is equipped with a lateral handle.

### Electrical characteristics

- rated short-time withstand current (Icw) = 4.5 kA rms / 1 second.
- rated peak withstand current (Ipk) = 20 kA peak.
- rated insulation voltage (Ui) = 690 V AC.

041153



### Multi-stage distribution block 125 A (40°C)

- 4 x 10 holes (5 x 10 mm<sup>2</sup>, 4 x 16 mm<sup>2</sup>, 1 x 35 mm<sup>2</sup>).

dimensions: width 88 mm, height 92 mm, depth 51 mm, distance between fixing centres 68 mm.

- 4 x 17 holes (8 x 10 mm<sup>2</sup>, 8 x 16 mm<sup>2</sup>, 1 x 35 mm<sup>2</sup>).

dimensions: width 125 mm, height 92 mm, depth 51 mm, distance between fixing centres 105 mm.

- supplied with insulating cover

- easy mounting on Multifix or symmetrical rail

- mounting on slotted plate using screws.

### Electrical characteristics

- rated short-time withstand current (Icw) = 3.5 kA rms / 1 second
- rated peak withstand current (Ipk) = 20 kA peak
- rated insulation voltage (Ui) = 500 V AC.



One-piece spreader

Connection of large cables may require an increase in the distance between the switch-disconnector terminals. The one-piece spreader is an accessory that can also be fitted on Compact NS circuit breakers. It offers the following features:


- increases the pitch of the switch-disconnector terminals to correspond to that of the upstream device
- compatible with all the connection and insulation accessories available for the upstream device (connectors, terminal extensions, etc.)
- enhances insulation between phases in comparison with standard spreaders.

	<b>INS250 INV100 to 250</b>	<b>INS320 to 630 INV320 to 630</b>
Pitch <b>without</b> spreaders (mm)	35	45
Pitch <b>with</b> standard spreaders (mm)	45	52.5 or 70
Pitch <b>with</b> one-piece spreader (mm)	45	70


#### Mounting

When equipped with a one-piece spreader, INS and INV switch-disconnectors may be installed either at the back of a switchboard or on the front panel with a front alignment base.


- devices with different frame sizes can thus be aligned in the switchboard
- the same mounting plate can be used for all devices (including Compact NS circuit breakers).



Connection and insulation accessories are identical to those for Compact NS




Mounting at the back of a switchboard



Mounting on the front panel with a front alignment base

# Insulation of live parts



056053 avec buse

## Terminal shields for INS and INV switch-disconnectors

Lead-sealable insulation accessories used to protect against direct contact with power circuits.

- degree of protection IP 40
- supplied with lead-sealing accessories.

## Phase barriers for INS/INV100 to 630

- safety accessories providing maximum insulation between the phases of the power connection
- easy installation by snapping into the case
- may be combined with all other connection accessories, except the terminal shields and terminal shrouds.

## Phase barriers for IN1000 to 2500



These devices may be equipped with phase barriers.

## Terminal shrouds for INS40 to 160



These insulation accessories are used for protection against direct contact with live connection screws. It is also possible to attach an insulating plate (not supplied) to the shrouds to avoid any contact with the power conductors.

## Spare viewport for Interpact INV switch-disconnectors


Viewports are darkened by the electrical arc. A new viewport may be installed to maintain the visible-break function.




Terminal shields for Interpact  
INS and INV



Phase barriers for Interpact  
INS and INV



Terminal shrouds for  
Interpact INS40 to 160  
(with insulating plate to avoid  
contact with the conductors)



Spare viewport for  
Interpact INV

## Auxiliary contacts

044314



Auxiliary contact for Interpact  
INS and INV

### Interpact INS and INV

One or four common-point changeover contacts can be used to remote switch-disconnector status information for indications, electrical interlocking, relays, etc.

#### Functions

Each contact may be used for the following functions:

- OF (open/closed): indicates the position of the switch-disconnector poles
- CAM (early-make or early-break function): indicates the position of the handle.

Used in particular for:


- CAO early-break switch (auxiliary contacts open before the main contacts), used, for example, to automatically open a circuit breaker or a contactor before opening the Interpact INS
- CAF early-make switch (auxiliary contacts close before the main contacts).
- switching of very small loads. A "low-level" version of the auxiliary switches exists for switching very small loads (for example, to control a PLC or electronic circuits).

#### Standards


The auxiliary switches comply with international standard IEC 60947-5-1.

#### Installation


They simply snap in under the auxiliaries cover (supplied as standard) of the switch-disconnector.



Interpact INS40 to 160



Interpact INS250  
and INV100 to 250



Interpact INS/INV 320 to 630

### Electrical characteristics of auxiliary contacts for Interpact INS and INV

		Standard				Low level			
Rated thermal current (A)		6				5			
Minimum load		10 mA at 24 V				1 mA at 4 V			
Utilisation category (IEC 60947-5-1)		AC		DC		AC		DC	
Operational current (A)		AC12	AC15	DC12	DC14	AC12	AC15	DC12	DC14
24 V		6	6	2.5	1	5	3	5	1
48 V		6	6	2.5	0.2	5	3	2.5	0.2
110 V		6	5	0.8	0.05	5	2.5	0.8	0.05
220/240 V		6	4			5	2		
250 V				0.3	0.03			0.3	0.03
380/415 V		6	3			5	1.5		
440 V		6	3			5	1.5		
660/690 V		6	0.1						

### Interpact IN1000 to IN2500


#### Possible combinations

Interpact	2 OF block	CAM block
IN1000, IN1600	1	+1
IN2500	1	+1

# Rotary handle




Interpact INS160 with lateral direct rotary handle



Interpact INS250 with lateral extended rotary handle



Interpact INS630 with front extended rotary handle



Interpact INS250 emergency-off version with front direct rotary handle

	INS40 to 160 INV100 to 250	INS250	INS320 to 630 INV320 to 630	IN1000 to 2500
<b>Standard rotary handle</b>				
Front direct	Standard	Standard	Standard	Standard
Lateral direct	Standard	With conversion	No	No
Front extended	Optional	Optional	Optional	Optional
Lateral extended	Optional (1) (2)	Optional	No	No
<b>Red and yellow rotary handle for emergency-off switch-disconnectors</b>				
Front direct	Standard	Standard	Standard	No
Lateral direct	Standard	With conversion	No	No
Front extended	Optional	Optional	Optional	No
Lateral extended	Optional (1) (2)	Optional (1)	No	No

(1) The basic switch-disconnector must be the emergency-off (red and yellow) version

(2) Two models for universal enclosures and for Prisma G enclosures.


## Interpact INS and INV

### Direct rotary handle


- degree of protection IP 40
- the switch-disconnector may be locked in the OFF position by one to three padlocks, hasp diameter 5 to 8 mm (not supplied).

#### Models


- standard with black handle
- emergency-off version with red handle and yellow front for machine-tool control.



Direct rotary handle on INS40 to 160



Direct rotary handle on INS250 and INV100 to 250



Direct rotary handle on INS/INV320 to 630

### Extended rotary handle

Makes it possible to operate the switch-disconnector, installed inside a switchboard, from the front or side of the switchboard. The extended rotary handle may be installed on the front or the side of the switch-disconnector. Degree of protection IP 55.7.

#### Operation

- suitability for isolation is maintained.
- door opening is prevented when the switch-disconnector is in ON position (for front handle only).
- the switch-disconnector may be locked in the OFF position by one to three padlocks, hasp diameter 5 to 8 mm (not supplied). Locking prevents opening of the switchboard door (for front handle only).


#### Models

- standard: with black handle.
- emergency-off: with red handle and yellow front for machine-tool control.

#### Installation

The extended rotary handle is made up of:

- an assembly that replaces the direct rotary handle on the Interpact switch-disconnector (secured by screws);
- an assembly (handle and front plate) to be mounted on the door or the side of the switchboard. This assembly is always secured in the same position, whether the switch-disconnector is installed vertically or horizontally;
- an adjustable extension shaft (see pages 3.0040).



## Interpact IN1000 to IN2500

### Extended rotary handle (IP 55)

The extended handle is obtained by adding a set of optional accessories to the standard direct rotary handle (front or lateral).

The accessories include:

- a front plate
- an extension shaft.

The extended rotary handle can be optionally fitted with:

- a door interlock that prevents door opening when the handle is not in the OFF position.

## Disabling device closing




Padlocked Interpact INS250 switch-disconnector


056849

### Padlocking

Interpact INS and INV switch-disconnectors may be locked in the OFF position. The handle is designed for locking by up to three padlocks (not supplied). Locking in the OFF position guarantees isolation as defined by the IEC 60947-3 standard. The handle may also be lead-sealed in the OFF position.



Device with padlocks



Device with keylock

### Keylocking

Interpact INS250 to 630, INV100 to 630 and IN1000 to IN2500 switch-disconnectors may be locked in the OFF position using a keylock (optional) that may be installed in the hole prepared for that purpose on the front of the devices. The key may not be removed when the switch-disconnector is in the ON position. Keylocks can also be fitted on switch-disconnectors equipped with extended rotary handles.

Type of locking	Type of rotary handle			
	Front direct	Front extended	Lateral direct	Lateral extended
Locking by 3 padlocks	<b>ON (I)</b> <input checked="" type="checkbox"/> (1)	<input checked="" type="checkbox"/> (1)	<input checked="" type="checkbox"/> (1)	<input checked="" type="checkbox"/> (1)
	<b>OFF (O)</b> <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Locking by Ronis or Profalux keylock	<b>ON (I)</b> <input checked="" type="checkbox"/> (1)	<input checked="" type="checkbox"/> (1)	<input checked="" type="checkbox"/> (1)	<input checked="" type="checkbox"/> (1)
	<b>OFF (O)</b> <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Door locking	<b>ON (I)</b> <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
Door lock defeat	<b>ON (I)</b> <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> (2)		
Door locking, device padlocked	<b>OFF (O)</b> <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		

(1) By simple modification of the standard rotary handle.


(2) Using a special tool.

# Switching to a replacement source

**Source-changeover systems are essential for continuity of service and energy management.**

**They switch between:**

- **a normal source N which supplies the installation under normal conditions;**
- **a replacement source R which can be another feeder or an engine-generator set.**




A source-changeover system is made up of two switch-disconnectors that are mechanically interlocked. The mechanism prevents the simultaneous connection (even transient) of both sources. Switching from one source to another can be achieved by:

- a keylock-type interlocking system
- a mechanical interlocking system
- a complete source-changeover assembly.

Change-over system	INS40...160	INS250 INV100...250	INS320...630 INV320...630	IN1000...2500
Keylock	■	■	■	■
Mechanical	■	■	■	
Complete assembly	■	■	■	

## Interlocking with keylocks


The two Interpact switch-disconnectors are each fitted with a standard keylock, but only one key is supplied for the two devices. This solution enables two distant switch-disconnectors to be interlocked.



Interlocking with keylocks

## Mechanical interlocking

A mechanism connects the handles of two Interpact switch-disconnectors equipped with direct handles. The mechanism prevents both switch-disconnectors from being closed at the same time, but does allow opening of both.




Mechanical interlocking

## Complete source changeover assembly

These assemblies provide an easy way to implement source changeover functions with:

- a single 3-position rotary handle that controls the two switch-disconnectors (Normal source ON, OFF, Replacement source ON)
- a smaller size, taking up less room in the switchboard.

A complete source changeover assembly can be ordered with a single catalogue number.




Complete source changeover assembly

## Downstream coupling accessory

This accessory is used to couple two switch-disconnectors of the same size.

- for Interpact INS250 and INV100 to 250, the pitch between outgoing terminals is 35 mm.
- for Interpact INS/INV320 to 630, the pitch between outgoing terminals is 52.5 mm.

The coupling accessory can be fitted with the same connection and insulation accessories as the switch-disconnectors.



Downstream coupling accessory

000008

*Photo à venir*

## Ammeter module

For Interpact INS250 to 630 and INV100 to 630.

### Function

Measures and displays the current of each phase (phase selection by a three-position switch on the front) on a dial-type ammeter.

### Installation

- connects directly to the downstream terminals of the switch-disconnector (except on a INS250 with a direct handle)
- the ammeter clips into the module housing in any of four 90° positions, i.e. the switch-disconnector may be installed horizontally or vertically
- degree of protection IP40
- class II insulation between front and power circuits.

### Electrical characteristics

Accuracy class 4.5.

*Interpact INS250 with ammeter module*

000009

*Photo à venir*

## Current-transformer module

For Interpact INS250 to 630 and INV100 to 630.

### Function

Measure phase currents for display by an ammeter or a Digipact IM or PM module (not supplied, see the corresponding catalogue).

### Installation

- connects directly to the downstream terminals of the switch-disconnector
- degree of protection IP40
- class II insulation between front and power circuits
- connection via six built-in terminals for cables with a cross-sectional area of 2.5 mm<sup>2</sup>.

### Electrical characteristics

- current transformer with 5 A secondary winding
- accuracy class 3 for the following values of consumed output power:
  - 100 A rating - 1.6 VA
  - 150 A rating - 3 VA
  - 250 A rating - 5 VA
  - 400/630 A rating - 8 VA.


*Interpact INS250 with current-transformer module*

# Accessories


## Front-panel escutcheons

### Escutcheons for switch-disconnectors and ammeter modules

Mounted on switchboard panel from the front using four screws.



Escutcheon for switch-disconnectors




Escutcheon for ammeter modules

## Identification labels

Interpact INS40 to 160 switch-disconnectors may receive Telemecanique prefabricated labels, catalogue number AB1- (eight characters). Interpact INS250 to 630 and INV100 to 630 switch-disconnectors are supplied as standard with a clip-on label for handwritten indications.

These devices also come with a nameplate into which a label can be inserted.



## Individual enclosures

Interpact INS and INV switch-disconnectors equipped with a front handle may be installed in individual enclosures.

All fixed, front connections are possible, except right-angle and edgewise terminal extensions. Spreaders may be installed in the enclosures intended for Interpact INS250 to 630 and INV100 to 630 switch-disconnectors.

### Heavy-duty metal individual enclosure for Interpact INS (IP547)

- metal enclosure
- door with keylock and cut-out for switch-disconnector rotary handle
- extended rotary front handle
- device mounting plate
- removable plate (without holes) for cable entry through bottom.

### Heavy-duty insulating individual enclosure for Interpact INS and INV (IP557)

- metal enclosure
- transparent cover, screwed, lead sealable, with cut-out for switch-disconnector rotary handle
- extended rotary front handle
- device mounting plate
- removable plates (without holes) for cable entry through bottom and/or top.

### Dimensions

Metal enclosures	W x H x D
Interpact INS40 to 160	300 x 200 x 150
Interpact INS250	300 x 400 x 200
Interpact INS320 to 630	400 x 600 x 200

Insulating enclosures	W x H x D
Interpact INS40 to 160	270 x 180 x 185
Interpact INS250	270 x 360 x 235
Interpact INV100 to 250	
Interpact INS320 to 630	360 x 720 x 235
Interpact INV320 to 630	






# Installation and connection

---


<i>LV switch-disconnectors</i>	1
<i>Presentation</i>	7
<i>Functions and characteristics</i>	15
<b>Possible installation positions and mounting techniques</b>	<b>46</b>
<b>Implementation</b>	<b>47</b>
<b>Front connection of bare copper and aluminium cables</b>	<b>48</b>
<b>Front connection of insulated bars and cables with crimped lugs</b>	<b>50</b>
<b>Front connection with accessories</b>	<b>52</b>
<b>Rear connection of Interpact INS250 to 630 and INV100 to 630</b>	<b>55</b>
<b>Installation of Interpact INS40 to 160</b>	<b>56</b>
<b>Extended handle for Interpact INS40 to 160</b>	<b>58</b>
<b>Installation of Interpact INS250 to 630, INV100 to 630</b>	<b>60</b>
<b>Installation of Interpact IN1000 to 2500</b>	<b>62</b>
<b>Installation of mechanical interlocks for direct handles (INS250 to 630, INV100 to 630)</b>	<b>64</b>
<b>Installation of mechanical interlocks for direct handles (INS40 to 630, INV100 to 630)</b>	<b>65</b>
<b>Installation of downstream coupling (INS250 to 630, INV100 to 630)</b>	<b>66</b>
<b>Installation of one-piece source changeover</b>	<b>68</b>
<i>Technical details</i>	69
<i>Catalogue numbers</i>	75

## Possible installation positions and mounting techniques


### Possible installation positions




### Possible mounting techniques INS40 to 160



### INS250 to 630 - INV100 to 630 - IN1000 to 2500




# Implementation



## Reverse supply

Interpact switch-disconnectors may be supplied indifferently via the top or bottom terminals, without any reduction in performance.



## Neutral pole position

On Merlin Gerin switch-disconnectors, the neutral pole is traditionally located on the left-hand side. On the INS and INV ranges, the four poles are identical and the neutral pole can therefore be located on the right-hand side simply by adding an appropriate label.

## Conductor materials and electrodynamic forces

Interpact switch-disconnectors may be connected using either bare copper, tinned copper or tinned aluminium conductors (flexible or rigid bars, cables).

In the event of a short-circuit, thermal and electrodynamic forces are exerted on the conductors. The conductors must therefore be adequately sized and suitably supported.

Note that the terminals of electrical devices (switch-disconnectors, contactors, circuit breakers, etc.) should not be considered to contribute to the support of the conductors.

## Cables ties and flexible bars


The table below indicates the maximum distances between cable ties depending on the prospective short-circuit current.

Care must be taken not to exceed a distance of 400 mm between ties mechanically secured to the switchboard frame.


Type of tie	"Panduit" type Width: 4.5 mm Max. load: 22 kg Colour: white			"Sarel" type Width: 9 mm Max. load: 90 kg Colour: black			
Max. distance between ties (mm)	200	100	50	350	200	100	70
Short-circuit current (kA rms)	10	15	20	20	27	35	45

**Note:** for cables  $\geq 50 \text{ mm}^2$ , 9 mm wide ties must be used.


# Front connection of bare copper and aluminium cables



If  $500 \text{ V} \leq U \leq 690 \text{ V}$ ,  
phase barriers or long  
terminal shields are  
mandatory



If  $500 \text{ V} \leq U \leq 690 \text{ V}$ ,  
phase barriers or long  
terminal shields are  
mandatory



If  $500 \text{ V} \leq U \leq 690 \text{ V}$ ,  
phase barriers or long  
or short terminal  
shields are mandatory


## Interpact INS40 to INS80

Interpact INS40 to INS80 switch-disconnectors are equipped as standard with connectors for bare copper and aluminium cables.

Distribution connectors may be screwed directly to the switch-disconnector terminals and can be used to connect three cables.

	Standard device	With distribution connector
Pole pitch	18 mm	18 mm
e (mm)	$\leq 5$	-
L (mm)	$\leq 10$	$\leq 10$
L1 (mm)	13	-
S ( $\text{mm}^2$ )	1.5 to 50 rigid	1.5 to 16 rigid (1)
Cu / Al	1.5 to 35 flexible	1 to 10 flexible (1)
Torque	5 Nm	2 Nm

(1) Connection of 1.5 to 4  $\text{mm}^2$  flexible cables requires crimped or auto-crimping ferrules.



Distribution connector


## Interpact INS100 to INS160

■ 1-cable connectors snap directly onto the device terminals.

■ distribution connectors for 4 flexible cables are screwed directly to the device terminals.

These connectors are supplied with phase barriers (mandatory installation) which may be replaced by long terminal shields.

■ Distribloc distribution block supplied via tunnel terminals. Provides 12 screwless spring type and 1 screw type outgoing terminals.




4-cable distribution connector

	1-cable connector	4-cable distribution connector
L (mm)	15	15
S ( $\text{mm}^2$ )	10 to 95 rigid	1.5 to 25 rigid
Cu / Al	10 to 95 flexible	1.5 to 16 flexible (1)
Torque (Nm)	10	3

### Distribloc see page 35

Torque (Nm) alimentation 5 Nm  
distribution 3 Nm



Distribloc

(1) Connection of 1.5 to 4  $\text{mm}^2$  flexible cables requires crimped or auto-crimping ferrules.

## Interpact INS250 and INV100 to 250

■ 1-cable connectors snap directly on to the device terminals or are clipped on to the right-angle or straight terminal extensions or spreaders.


These connectors are supplied with phase barriers.

Material: steel  $I \leq 160 \text{ A}$  and tinned aluminium  $I \leq 250 \text{ A}$ .

■ 6-cable distribution connectors are screwed directly to the device terminals. These connectors are supplied with phase barriers (mandatory installation) which may be replaced by long terminal shields.

Material: tinned aluminium.

■ Polybloc distribution blocks, for 6 or 9 rigid or flexible cables, are connected directly to the device terminals. Cable connection is made in spring type terminals and does not require screws.



Distribution connector

	1-cable connector	Steel $\leq 160\text{A}$	Aluminium $\leq 250\text{A}$
L (mm)	20	20	
S ( $\text{mm}^2$ ) Cu / Al	1.5...95 <sup>(1)</sup>	10...16	25...35 50...185
Torque (Nm)	12	15	20 26


### Distribution connector, 6 cables Cu or Al

L (mm)	15 or 30
S ( $\text{mm}^2$ ) Cu / Al	1.5...6 <sup>(1)</sup> 8...35
Torque (Nm)	4 6


### Polybloc distribution block, 6 or 9 cables

L (mm)	12
S ( $\text{mm}^2$ ) Cu / Al	1.5...10

(1) Connection of 1.5 to 4  $\text{mm}^2$  flexible cables requires crimped or auto-crimping ferrules.




Polybloc distribution block





### Interact INS250 and INV100 to 250 (cont.)

#### Dimensions 1-cable connector



#### 6-cable distribution connector




### Interact INS/INV320 to 630

1-cable or 2-cable connectors made of tinned aluminium, for copper or aluminium cables, are screwed to the device terminals or to right-angle terminal extensions. These connectors are supplied with phase barriers.


	1-cable connector	2-cable connector
L (mm)	30	30 or 60
S (mm <sup>2</sup> )	35 to 300 rigid	35 to 240 rigid
Cu / Al	35 to 300 flexible	35 to 240 flexible
Torque (Nm)	31	31

O S




#### Dimensions

##### 1-cable connector




##### 2-cable connector




If  $500 \text{ V} \leq U \leq 690 \text{ V}$ ,  
phase barriers or long  
or short terminal  
shields are mandatory.

# Front connection of insulated bars and cables with crimped lugs



If  $500 \text{ V} \leq U \leq 690 \text{ V}$ ,  
phase barriers or long  
or short terminal  
shields are mandatory



If  $500 \text{ V} \leq U \leq 690 \text{ V}$ ,  
phase barriers or long  
or short terminal  
shields are mandatory


## Interpact INS100 to INS160

Interpact INS100 to INS160 switch-disconnectors are equipped as standard with terminals comprising nuts with M6 screws, for direct connection of insulated bars and cables with crimped lugs.

### Lugs

The small lugs for copper cables may be used for cables with cross-sectional areas up to  $95 \text{ mm}^2$ . Crimping by hexagonal necking or punching. Lugs are supplied with phase barriers and are compatible with the terminal shields.

INS100 to 160	
Pole pitch	30 mm
d (mm)	$\leq 10$
I (mm)	$d + 10$
e (mm)	2...6.4
L (mm)	15
L1 (mm)	$\leq 21$
Dia. (mm)	$\geq 6.2$
Torque (Nm)	8
Bars, lugs	



Small lugs for copper cables

## Interpact INS250 to 630 and INV100 to 630

Interpact INS250 to INS630 and INV100 to INV630 switch-disconnectors are equipped as standard with terminals receiving snap-in nuts and screws (M8 for INS/INV up to 250, M10 from 320 upwards) for direct connection of insulated bars or cables with lugs.

### Lugs


Lugs are different for copper and aluminium cables. They are supplied with phase barriers and are compatible with the long terminal shields.

- the small lugs for copper cables may be used for cables with the following cross-sectional areas:
  - 120, 150 or  $185 \text{ mm}^2$  (INS/INV up to 250);
  - 240 or  $300 \text{ mm}^2$  (INS/INV up to 630).
 Crimping by hexagonal necking or punching.
- the small lugs for aluminium cables may be used for cables with the following cross-sectional areas:
  - 150 or  $185 \text{ mm}^2$  (INS/INV up to 250);
  - 240 or  $300 \text{ mm}^2$  (INS/INV up to 630).
 Crimping by hexagonal necking.

INS250		INS320 to 630
INV100 to 250	INV320 to 630	
Pole pitch	35 mm	45 mm
d (mm)	$\leq 10$	$\leq 15$
I (mm)	$d + 10$	$d + 10$
e (mm)	$\leq 6$	$3 \leq e \leq 10$
L1 (mm)	$\leq 25$	$\leq 32$
Dia. (mm)	$\geq 10$	$\geq 10$
Torque (Nm)	15	50




Small lugs for copper cables




Small lugs for aluminium cables

### Dimensions

INS250  
INV100 to 250




INS320 to 630  
INV320 to 630




If  $500 \text{ V} \leq U \leq 690 \text{ V}$ ,  
phase barriers are  
mandatory

### Interpact IN1000 to 2500



# Front connection with accessories




If  $500 \text{ V} \leq U \leq 690 \text{ V}$ ,  
phase barriers or long  
or short terminal  
shields are mandatory

## Interpact INS250 and INV100 to 250

### Spreader


Material: tinned copper



E18590

### Straight terminal extensions

Material: tinned copper




E18601

### Right-angle terminal extensions

Material: tinned copper  
Installation on upstream  
terminals




E18600




E55699

One-piece spreader



E25961

Connection of two cables  
with lugs



E25969

Connector with clip for bare  
cables

### Pole pitch

Without spreader 35 mm

With spreader 45 mm

### Dimensions with spreader

E50702


Dimensions	Bars	L (mm)	$\leq 25$
	Lugs	I (mm)	$d + 10$
		d (mm)	$\leq 10$
		e (mm)	$\leq 6$
		Dia. (mm)	8.5
		L (mm)	$\leq 25$
		Dia. (mm)	8.5
Torque	(Nm)	15 (1)	

(1) Tightening torque for spreader

Spreaders, straight terminal extensions and right-angle terminal extensions are supplied with phase barriers.


### Dimensions

Right-angle terminal  
extensions




E55436

Spreader and straight terminal extensions



E55440


One-piece spreader



E55342

With front alignment base

Without front alignment base




If  $500 \text{ V} \leq U \leq 690 \text{ V}$ ,  
phase barriers or long  
or short terminal  
shields are mandatory

## Interpact INS/INV320 to 630


### Spreader

Material: tinned copper




### Edgewise terminal extensions

Material: tinned copper



### Right-angle terminal extensions

Material: tinned copper  
Installation on upstream terminals



One-piece spreader.  
1-cable and 2-cable  
connectors for bare cables

### Pole pitch

Without spreader

45 mm

With spreader


52.5 or 70 mm

### Dimensions

#### with spreader

#### with edgewise terminal extensions

E50702



L (mm)	$\leq 40$	$\leq 32$
d (mm)	$d + 15$	$30 \leq d \leq 34$
e (mm)	$\leq 20$	$\leq 15$
Dia. (mm)	3 $\leq e \leq 10$	3 $\leq e \leq 10$
L (mm)	12.5	> 10.5
Torque (Nm)	$\leq 40$	$\leq 32$
	50 (1)	10.5
		50 (1)

(1) Tightening torque for spreader and extensions.



Spreaders, edgewise terminal extensions and right-angle terminal extensions are supplied with phase barriers.

### Dimensions

Edgewise terminal extensions


Right-angle terminal extensions

E55444



### Spreader

E55442



### Type

INS320/630, INV320/630

K8

K9

52.5 187.5


width in mod. of 52.5 mm

width in mod. of 70 mm

70 240

## Interpact NI1000 to 2500


### Spreader




(1) 16 mm for IN1600

### Edgewise terminal extensions

#### IN1000





#### IN1600



### Connector


#### IN2500

If  $500 \text{ V} \leq U \leq 690 \text{ V}$ , phase barriers are mandatory.

### Phase barriers

- distribution blocks, lugs, right-angle/straight/edgewise terminal extensions and spreaders are supplied with phase barriers.
- phase barriers may be positioned horizontally or vertically.
- they may be replaced by long terminal shields.

# Rear connection of Interpact INS250 to 630 and INV100 to 630



If  $500 \text{ V} \leq U \leq 690 \text{ V}$ ,  
short terminal shields  
are mandatory

## Bars or cables with crimped lugs

Interpact INS250 to 630 and INV100 to 630 switch-disconnectors may be equipped with long or short rear connections, or a mix of the two.


The connections may be positioned flat, on edge or at 45° angles, or any combination thereof.

Material of rear connections: tinned copper.


INS250	INS320 to 630
INV100 to 250	INV320 to 630

<b>Bars</b>		
L (mm)	$\leq 25$	$\leq 32$
I (mm)	$d + 10$	$d + 15$
d (mm)	$\leq 10$	$\leq 15$
e (mm)	$\leq 6$	$3 \leq e \leq 10$
Dia. (mm) >	8	10.5
<b>Lugs</b>		
L (mm)	$\leq 25$	$\leq 32$
Dia. (mm) >	8	10.5
<b>Torque (Nm)</b>	5 (1)	20 (1)


(1) Tightening torque for rear connections.



Connection of bars or cables  
with lugs




Two lengths




Four positions

## Dimensions

### INS250 and INV100 to 250





### INS/INV320 to 630



## Bare cables (copper or aluminium)


For Interpact INS250 and INV100 to 250 switch-disconnectors, the rear connections may be equipped with 1-cable connectors secured by clips.




If  $500 \text{ V} \leq U \leq 690 \text{ V}$ ,  
short terminal shields  
are mandatory

## Dimensions

### Front handle



### Lateral handle




### Dimensions (mm)


Type	H	H1	H2	H3	H4	H5	H6	H7	K	K1	L	L1	L2	L3	P	P1	P2	P3	P4	P5	P6	P7
INS40/63/80	22.5	45	40.5	81	42.5	85	73.5	147	1	18	46	73	90	109	21.3	43	47	62.5	79	5	40	66.1
INS100/125/160	22.5	45	50	100	50	100	110	220	7.5	30	67.5	119	135	154	18.5	45	47	62.5	79	5	42.5	69.3

## Installation

### On a backplate




### On a rail



#### Dimensions (mm)

Type	C1	C2	R1	R2	ØT	U
INS40/63/80	40	80	10	36	4.5	35
INS100/125/160	37.5	75	22.5	60	4.5	35

## Front panel cutout




#### Dimensions (mm)


Type	C	R
INS40/63/80	47	92
INS100/125/160	47	137

## Front handle

E32609



E32610




Dimensions (mm)



Type	A (on backplate) mini	A (on backplate) maxi	B (on rail) mini	B (on rail) maxi	e	K	Length of shaft
INS40/63/80	128	519	123	514	1...3	1	A - 69
INS100/125/160	128	519	123	514	1...3	7.5	A - 69

## Door or front panel cutout for front handle

E32611





### Standard lateral handle



Dimensions (mm)

Type	B mini	B maxi	e	P6	Length of shaft
With shaft					
INS40/63/80	155	396	1...3	40	B - 95
INS100/125/160	200	441	1...3	42.5	B - 140
Without shaft	B	e	P6		
INS40/63/80	102		1...3	40	
INS100/125/160	147		1...3	42.5	


### Lateral handle for functional enclosure



Dimensions (mm)

Type	Length of shaft	Type	B	e	P6
Enclosure					
INS40/63/80	550 mm	short	149	1...3	41.5
	600 mm	long	174	1...3	41.5
INS100/125/160	550 mm	short	194	1...3	41.5
	600 mm	long	219	1...3	41.5




### Side cutout



# Installation of Interpact INS250 to 630 INV100 to 630

## Dimensions

### Front handle





(a) Terminal shields  
(b) Phase barriers

### Dimensions (mm)



Type	H	H1	H2	H3	H4	H5	H6	H7	H8	K	K1	L	L1	P	P1	P2	P3	P4
INS250	40	80	68	136	148	296	166	332	115	17.5	35	70	140	21.5	86	96	131	138
INV100/250																		
INS320/630	61.5	123	102.5	205	215	430	—	—	177	22.5	45	92.5	185	26	120	160.4	162	—
INV320/630																		

### Lateral handle for INS250 and INV100/250



#### Front handle



#### Direct extended




### Extended front handle




Dimensions (mm)

Type	A mini	A maxi	e	K	Length of shaft A
INS250	185	600	1...3	17.5	101
INS400/630	204	600	1...3	22.5	124

### Installation on a backplate



### Door cutout




Dimensions (mm)


Type	H9	H10	H11	L3	L4	L5	L6
INS250	82	50	100	65.5	131	35	70
INS400/630	127	75	150	85.5	171	45	90

### Door or front panel cutout for extended handle

#### Front




#### Lateral (INS250 and INV100/250)



#### Note:

Lines X and Y indicate the axes of symmetry of the switch-disconnector.  
Reference plane Z corresponds to the back of the switch-disconnector.

## Dimensions




## Dimensions (mm)


Type	Cmax.	D	D1	D2	D3	H	H1	H2	H3	H4	H5	T	T1	W	W1	W2
IN1000/1600	223.5	211.5	118	110	104.5	235	117.5	300	150	540	270	50	105	410	170	340
IN2500	305.5	311.5	200	192	180	235	117.5	440	220	540	270	50	105	410	170	340

## Installation


## On rails



## On a backplate




## Door cutout



## Dimensions (mm)

Type	A	C	C1	R	R1
IN1000/1600	110	185	92.5	188	149
IN2500	192	185	92.5	188	149

## Extended front handle




Dimensions (mm)

Type	A (*) mini	maxi	e	F	T
IN1000/1600	180	306	1...4	109	50
IN2500	262	388	1...4	127	50

(\*) To compensate the vertical play of the shaft, reduce T by 3 mm when d > 220 mm



## Door or front panel cutout for extended handle



## Installation of mechanical interlocks for direct handles

(INS250 to 630, INV100 to 630)


### Direct handle



Dimensions (mm)

Type	A	B	C	D	E	F	G	P	Q
INS250	325	90	87.5	175	70	156	106	68	136
INV100/250									
INS320/630	416	115	100	200	92.5	210	130	102.5	205
INV320/630									

### Door cutout for direct handle





Dimensions (mm)

Type	F	H	K	L	M	N
INS250	156	17.5	295	75.5	150	75
INV100/250						
INS630	210	22.5	386	100	175	74.5
INV320/630						

# Installation of mechanical interlocks for extended handles

(INS40 to 630, INV100 to 630)


## Extended handle



Dimensions (mm)

Type	A	B	C	D	E	F	G mini	G maxi	P	Q
INS40	325	90	87.5	175	46	156	155	396	45	90
INS160	325	90	87.5	175	70	156	200	441	50	100
INS250	325	90	87.5	175	70	156	185	600	68	136
INV100/250										
INS320/630	416	115	100	200	92.5	210	204	600	102.5	205
INV320/630										

## Door cutout for extended handle



Dimensions (mm)

Type	F	H
INS40 to INS160	156	0
INS250	156	17.5
INV100/250		
INS320/630	210	22.5
INV320/630		


**Note:**

Lines X and Y indicate the axes of symmetry of the switch-disconnector.  
Reference plane Z corresponds to the back of the switch-disconnector.


## Installation of downstream coupling

(INS250 to 630, INV100 to 630)


### Dimensions



### Coupling dimensions



### Connection






### Dimensions (mm)




Type	G2	G3	G28	G29	G30	G52	K1	K2	K3	K4	K8	K9	K16
<b>INS250</b> <b>INV100/250</b>	105.5	169	225.2	83.5	127.5	143.5	35	35	51	156	57.5	157.5	25.4
<b>INS320/630</b> <b>INV320/630</b>	141	240.7	315	118.4	163.4	202.5	45	52.5	75	210	88.5	225.7	26.1
Type	L28	L29	L30	L31	L32	L33	L34	L35	L36	L37	L38	L39	L40
<b>INS250</b> <b>INV100/250</b>	320	82.2	300	72.2	16.4	123	139.5	74.5	19.5	70	21.5	24.9	140
<b>INS320/630</b> <b>INV320/630</b>	420	105.2	400	95.2	11.1	187.5	184.7	96.5	24	92.5	26	22.4	210

## Front-panel escutcheon

### For switch-disconnector



### For ammeter module



Dimensions (mm)

Type	A2	D1	D2	M6	M7
INS250 INV100/250	174	3.5	6.5	114	101
INS320/630 INV320/630	215.5	3.5	6.5	164	151


**INFO TO COME**

# Technical details

---

<i>LV switch-disconnectors</i>	1
<i>Presentation</i>	7
<i>Functions and characteristics</i>	15
<i>Installation and connection</i>	45
<b>Protection of switch-disconnectors</b>	<b>70</b>
<b>Use at high temperatures</b>	<b>74</b>
<i>Catalogue numbers</i>	75

# Protection of switch-disconnectors



## Interpact INS switch-disconnectors

### Upstream protection

<b>By circuit breaker 380/415 V</b>	type / max. rating (A)	
	Isc max.	kA rms
	making capacity	kA peak
	type / max. rating (A)	
	Isc max.	kA rms
	making capacity	kA peak
	type / max. rating (A)	
	Isc max.	kA rms
	making capacity	kA peak
	type / max. rating (A)	
<b>By circuit breaker 440/480 V (*)</b>	Isc max.	kA rms
	making capacity	kA peak
	type / max. rating (A)	
	Isc max.	kA rms
	making capacity	kA peak
	type / max. rating (A)	
	Isc max.	kA rms
	making capacity	kA peak
	type / max. rating (A)	
	Isc max.	kA rms
<b>By fuse 500 V</b>	making capacity	kA peak
	type aM <b>(1)</b> / max. rating (A)	
	Isc max.	kA rms
	making capacity	kA peak
	type gG <b>(2)</b> / max. rating (A)	
	Isc max.	kA rms
	making capacity	kA peak
	type gG <b>(1)</b> / max. rating (A)	
	Isc max.	kA rms
	making capacity	kA peak
<b>type BS <b>(2)</b> / max. rating (A)</b>		
	Isc max.	kA rms
<b>type BS <b>(1)</b> / max. rating (A)</b>		
	Isc max.	kA rms
	making capacity	kA peak


(\*) Applicable for 480 V NEMA

(1) Mandatory protection by an external thermal relay

(2) No external thermal protection

	<b>INS40</b>	<b>INS63</b>	<b>INS80</b>	<b>INS100</b>	<b>INS125</b>	<b>INS160</b>
	NS100N / 40 25 52	NS100N / 63 25 52	NS100N / 80 25 52	NS100N / 100 25 52		
	NS100H-L / 40 36 75	NS100H-L / 63 36 75	NS100H-L / 80 36 75	NS100H-L / 100 70 154		
	NS160N / 40 25 52	NS160N / 63 25 52	NS160N / 80 25 52	NS160-250N / 100 36 75	NS160-250N / 125 36 75	NS160-250N / 160 36 75
	NS160H-L / 40 25 52	NS160H-L / 63 25 52	NS160H-L / 80 25 52	NS160-250H-L / 100 70 154	NS160-250H-L / 125 70 154	NS160-250H-L / 160 70 154
	NSC100N / 40 18 37	NSC100N / 63 18 37	NSC100N / 80 18 37	NSC100N / 100 18 37		
	NG125N / 40 25 52	NG125N / 63 25 52	NG125N / 80 25 52	NG125N / 100 25 52	NG125N / 125 25 52	
	NG125H / 40 36 75	NG125H / 63 36 75	NG125H / 80 36 75			
	NG125L / 40 50 105	NG125L / 63 50 105	NG125L / 80 50 105			
	NSA160N / 40 30 63	NSA160N / 63 30 63	NSA160N / 80 30 63	NSA160N / 100 30 63	NSA160N / 125 30 63	NS160N / 160 30 63
	NS100N / 40 25 52	NS100N / 63 25 52	NS100N / 80 25 52	NS100N / 100 25 52		
	NS100H-L / 40 35 73	NS100H-L / 63 35 73	NS100H-L / 80 35 73	NS100H-L / 100 65 143		
	NS160N / 40 25 52	NS160N / 63 25 52	NS160N / 80 25 52	NS160-250N / 100 35 73	NS160-250N / 125 35 73	NS160-250N / 160 35 73
	NS160H-L / 40 25 52	NS160H-L / 63 25 52	NS160H-L / 80 25 52	NS160-250H-L / 100 65 143	NS160-250H-L / 125 65 143	NS160-250H-L / 160 65 143
	NSC100N / 40 18 37	NSC100N / 63 18 37	NSC100N / 80 18 37	NSC100N / 100 18 37		
40 80 176	63 80 176	80 80 176	100 80 176	125 55 121	160 33 69	
32 100 220	50 100 220	63 100 220	80 100 220	100 100 220	125 100 220	
125 100 220	125 100 220	125 100 220	160 100 220	160 100 220	160 100 220	
32 80 176	50 and 32M50 80 176	63 and 32M63 80 176	80 and 63M80 80 176	100 and 63M100 80 176	125 and 100M125 80 176	
125 and 100M125 80 176	125 and 100M125 80 176	125 and 100M125 80 176	160 and 100M160 80 176	160 and 100M160 80 176	160 and 100M160 80 176	

# Protection of switch-disconnectors



E51067

## Interpac INS switch-disconnectors

### Upstream protection

By circuit breaker 380/415 V	type / max. rating (A)	
	Isc max.	kA rms
	making capacity	kA peak
	type / max. rating (A)	
By circuit breaker 440/480 V (*)	Isc max.	kA rms
	making capacity	kA peak
	type / max. rating (A)	
	Isc max.	kA rms
By fuse 500 V	making capacity	kA peak
	type aM (1) max. rating (A)	
	Isc max.	kA rms
	making capacity	kA peak
By fuse 500 V	type gG (2) max. rating (A)	
	Isc max.	kA rms
	making capacity	kA peak
	type gG (1) max. rating (A)	
By fuse 500 V	Isc max.	kA rms
	making capacity	kA peak
	type BS (2) max. rating (A)	
	Isc max.	kA rms
By fuse 500 V	making capacity	kA peak
	type BS (1) max. rating (A)	
	Isc max.	kA rms
	making capacity	kA peak

## Interpac INS switch-disconnectors

### Downstream protection

By circuit breaker 380/415 V	type / max. rating (A)	
	Isc max.	kA rms
	making capacity	kA peak
	type / max. rating (A)	
By circuit breaker 440/480 V (*)	Isc max.	kA rms
	making capacity	kA peak
	type / max. rating (A)	
	Isc max.	kA rms
By fuse 500 V	making capacity	kA peak
	type aM (1) max. rating (A)	
	Isc max.	kA rms
	making capacity	kA peak
By fuse 500 V	type gG (2) max. rating (A)	
	Isc max.	kA rms
	making capacity	kA peak
	type gG (1) max. rating (A)	
By fuse 500 V	Isc max.	kA rms
	making capacity	kA peak
	type BS (2) max. rating (A)	
	Isc max.	kA rms
By fuse 500 V	making capacity	kA peak
	type BS (1) max. rating (A)	
	Isc max.	kA rms
	making capacity	kA peak

(\*) Applicable for 480 V NEMA

(1) Mandatory protection by an external thermal relay

(2) No external thermal protection

	<b>INS250-100 INV100</b>	<b>INS250-160 INV160</b>	<b>INS250-200 INV200</b>	<b>INS250 INV250</b>	<b>INS320 INV320</b>	<b>INS400 INV400</b>
	NS100-160-250N/100 25-25-36 53-53-75	NS160-250N/160 36 75	NS250N/200 36 75	NS250N/250 36 75	NS400-630N/320 45 94	NS400-630N/400 45 94
	NS100-160-250H/100 70 154	NS160-250H/160 70 154	NS250H/200 70 154	NS250H/250 70 154	NS400-630H/320 70 154	NS400-630H/400 70 154
	NS100-160-250L/100 150 330	NS160-250L/160 150 330	NS250L/200 150 330	NS250L/250 150 330	NS400-630L/320 150 330	NS400-630L/400 150 330
	NS100-160-250N/100 25-25-35 53-53-73	NS160-250N/160 35 73	NS250N/200 35 73	NS250N/250 35 73	NS400-630N/320 42 88	NS400-630N/400 42 88
	NS100-160-250H/100 65 143	NS160-250H/160 65 143	NS250H/200 65 143	NS250H/250 65 143	NS400-630H/320 65 143	NS400-630H/400 65 143
	NS100-160-250L/100 130 286	NS160-250L/160 130 286	NS250L/200 130 286	NS250L/250 130 286	NS400-630L/320 130 286	NS400-630L/400 130 286
	100 100 220	160 100 220	200 100 220	250 100 220	320 100 220	400 100 220
	80 100 220	125 100 220	160 100 220	200 100 220	250 100 220	315 100 220
	100 100 220	160 100 220	200 100 220	250 100 220	320 100 220	400 100 220
	80 and 63M80 80 176	125 and 100M125 80 176	160 and 100M160 80 176	200 and 100M200 80 176	250 and 200M250 80 176	315 and 200M315 80 176
	250 and 200M250 80 176	250 and 200M250 80 176	250 and 200M250 80 176	250 and 200M250 80 176	355 and 315M355 80 176	355 and 315M355 80 176
	<b>INS500 INV500</b>	<b>INS630 INV630</b>	<b>IN1000</b>	<b>IN1600</b>	<b>IN2500</b>	
	NS630N/630 45 94	NS630N/630 45 94	C1001-1251N/1000 40 84	CM / 1600 35 73	CM / 1600 35 73	
	NS630H/630 70 154	NS630H/630 70 154	C1001-1251H/1000 40 84	Masterpact / 1600 35 75	Masterpact / 2500 50 105	
	NS630L/630 150 330	NS630L/630 150 330	C1001L/1000 80 176			
	NS630N/500 42 88	NS630N/630 42 88	C1001-1251N/1000 40 84	CM / 1600 35 73		
	NS630H/500 65 143	NS630H/630 65 143	C1001-1251H/1000 40 84	Masterpact / 1600 35 75	Masterpact / 2500 50 105	
	NS630L/500 130 286	NS630L/630 130 286				
	500 100 220	500 100 220				
	400 100 220	500 100 220				
	500 100 220	630 100 220				
	400 80 176	500 80 176				
	450 and 400M450 80 176	450 and 400M450 80 176				

**Power dissipated and resistance per pole**

Interpact INS						
Rating	40	63	80	100	125	160
Resistance per pole	0.3	0.3	0.3	0.2	0.2	0.2
Power dissipated per pole	0.5	1.2	1.9	2	3.1	5.1
Interpact INS/INV						
Rating	250 (100)	250 (160)	250 (200)	250	320	400
Resistance per pole	0.15	0.15	0.15	0.15	0.06	0.06
Power dissipated per pole	1.5	4	6	9.5	6.1	9.6
Interpact IN						
Rating	1000	1600	2500			
Resistance per pole	0.032	0.02	0.01			
Power dissipated per pole	32	53	62.5			

*Resistance per pole in milliohms (mΩ)  
Power dissipated per pole in watts (W)*

**Temperature derating**

Interpact INS	40	63	80	100	125	160
Front connection with bare-cable connectors or lugs						
Thermal current Ith at 60 °C	40	63	80	100	125	160
Thermal current Ith at 65 °C	40	63	80	100	125	160
Thermal current Ith at 70 °C	40	63	80	100	125	150
Interpact INS	250 (100)	250 (160)	250 (200)	250	320	400
Interpact INV	100	160	250	250	320	400
Front connection / rear connection						
Thermal current Ith at 60 °C	100	160	200	250	320	400
Thermal current Ith at 65 °C	100	160	200	250	320	400
Thermal current Ith at 70 °C	100	160	200	250	320	400
Interpact INS	250 (100)	250 (160)	250 (200)	250	320	400
Interpact INV	100	160	250	250	320	400
Front connection with right-angle terminal extension + bare-cable connectors						
Thermal current Ith at 55 °C	100	160		250	320	400
Thermal current Ith at 60 °C	100	160	200	250	320	400
Thermal current Ith at 65 °C	100	160	200	250	320	400
Thermal current Ith at 70 °C	100	160	200	240	320	400
Interpact INS	250 (100)	250 (160)	250 (200)	250	320	400
Interpact INV	100	160	250	250	320	400
Front connection / rear connection with ammeter or CT module						
Thermal current Ith at 40 °C	100	160		250	320	400
Thermal current Ith at 50 °C	100	160		250	320	400
Thermal current Ith at 55 °C	100	160		250	320	400
Thermal current Ith at 60 °C	100	160	200	240	320	400
Thermal current Ith at 65 °C	100	160	200	230	320	400
Thermal current Ith at 70 °C	100	160	200	210	320	400
Interpact IN	1000	1600	2500			
Thermal current Ith at 50 °C	1000	1600	2500			
Thermal current Ith at 55 °C	1000	1520	2500			
Thermal current Ith at 60 °C	1000	1450	2500			
Thermal current Ith at 65 °C	1000	1360	2450			
Thermal current Ith at 70 °C	850	1270	2400			

*Thermal current Ith in Amps (QA)*


# Catalogue numbers

---


<i>LV switch-disconnectors</i>	1
<i>Presentation</i>	7
<i>Functions and characteristics</i>	15
<i>Installation and connection</i>	45
<i>Technical details</i>	69
<b>INS40 to 160</b>	<b>76</b>
<b>INS250 to 630</b>	<b>78</b>
<b>INV100 to 630 (visible break)</b>	<b>79</b>
<b>Accessories</b>	<b>80</b>
INS250 and INV100 to 250 (visible break)	80
INS320 to 630 and INV320 to 630 (visible break)	82
<b>IN1000 to 2500</b>	<b>84</b>

## Complete device

### Interpact INS40 to INS160 standard version with black handle




		3P	4P
Interpact INS40	Fixed/FC	28900	28901
Interpact INS63	Fixed/FC	28902	28903
Interpact INS80	Fixed/FC	28904	28905



		3P	4P
Interpact INS100	Fixed/FC	28908	28909
Interpact INS125	Fixed/FC	28910	28911
Interpact INS160	Fixed/FC	28912	28913

### Interpact INS40 to INS160 with red handle and yellow front



		3P	4P
Interpact INS40	Fixed/FC	28916	28917
Interpact INS63	Fixed/FC	28918	28919
Interpact INS80	Fixed/FC	28920	28921

		3P	4P
Interpact INS100	Fixed/FC	28924	28925
Interpact INS125	Fixed/FC	28926	28927
Interpact INS160	Fixed/FC	28928	28929

## Accessories


### Locks, interlocks and coupling accessories

#### Handle locking



By 1 to 3 padlocks (OFF position), hasp dia. 5 to 8 mm or by lead seals	built-in
--	----------

#### Interlock for extended rotary handles



Mechanical for INS40 to 160	28953
-----------------------------	-------

#### Spare parts

##### Handle for rotary control



INS40 to INS160	Front or lateral rotary control	black handle	28962
		red handle	28963

#### Mounting in enclosures

The following solutions have been taken from the Interpact catalogue


#### Individual enclosures

##### IP55 heavy-duty sheetmetal enclosure



For INS40 to INS160 with standard rotary handle	28965
For INS40 to INS160 with red rotary handle on yellow front	28966


##### IP55 insulating enclosure



For INS40 to INS160 with standard rotary handle	28967
For INS40 to INS160 with red rotary handle on yellow front	28968


## Connection accessories

### Distribloc distribution block (for bare cables)




INS40 to INS125	125 A, 12 outgoing spring terminals (7 x 4 <sup>2</sup> + 3 x 6 <sup>2</sup> + 2 x 10 <sup>2</sup> ) + 1 outgoing tunnel terminal (25 <sup>2</sup> )	<b>7105</b>
INS100 to INS160	160 A, 12 outgoing spring terminals (7 x 4 <sup>2</sup> + 3 x 6 <sup>2</sup> + 2 x 10 <sup>2</sup> ) + 1 outgoing tunnel terminal (25 <sup>2</sup> ) with prefabricated connections	<b>7106</b>

### Multi-stage distribution block (for bare cables)



INS40 to INS125	125 A, 4 X 10 holes (5 x 10 <sup>2</sup> + 4 x 16 <sup>2</sup> + 1 x 35 <sup>2</sup> )	<b>13512</b>
INS40 to INS125	125 A, 4 X 17 holes (8 x 10 <sup>2</sup> + 8 x 16 <sup>2</sup> + 1 x 35 <sup>2</sup> )	<b>13514</b>

### Bare cable connectors



Snap-on	INS100 to INS160 cables up to 95 <sup>2</sup>	set of 3 set of 4	<b>28947</b> <b>28948</b>
Distribution connector for 3 rigid cables up to 16 <sup>2</sup> or 3 flexible cables up to 10 <sup>2</sup>	INS40 to INS80	set of 3 set of 4	<b>19096</b> <b>19091</b>
Distribution connector for 4 rigid cables up to 25 <sup>2</sup> or 4 flexible cables up to 16 <sup>2</sup>	INS100 to INS160	set of 3 set of 4	<b>28949</b> <b>28950</b>

### Crimp lugs for copper cables



For 95 mm <sup>2</sup> cables with phase barriers	INS100 to INS160	set of 3 set of 4	<b>28951</b> <b>28952</b>
--	------------------	----------------------	------------------------------

### Terminal shrouds



INS40 to INS80	3P/4P	1 pair	<b>28955</b>
INS100 to INS160	3P/4P	1 pair	<b>28956</b>

### Terminal shields



INS40 to INS80	3P/4P	1 pair	<b>28957</b>
INS100 to INS160	3P/4P	1 pair	<b>28958</b>

### Phase barriers



INS100 to INS160	3P/4P	set of 6	<b>28959</b>
------------------	-------	----------	--------------

## Electrical auxiliaries

### Auxiliary contacts



1 OF / CAF / CAO (depending on how it is mounted)	INS40 to INS160	<b>29450</b>
1 OF / CAF / CAO (low level)	INS40 to INS160	<b>29452</b>

### Rotary handles


#### Accessories for conversion to extended rotary handles




Front control	with black handle	INS40 to INS160	<b>28941</b>
	with red handle on yellow front	INS40 to INS160	<b>28942</b>
Lateral control	with black handle	INS40 to INS160	<b>28943</b>
	with red handle on yellow front	INS40 to INS160	<b>28944</b>
Lateral control	with black handle	INS40 to INS160	<b>28945</b>
Functional enclosure G-GX-PRAGMA F	with red handle on yellow front	INS40 to INS160	<b>28946</b>

## Complete device

### Interpact INS250 to INS630 standard version




		3P	4P
E50985	Interpact INS250-100A	Fixed/FC	31100
	Interpact INS250-160A	Fixed/FC	31104
	Interpact INS250-200A	Fixed/FC	31102
	Interpact INS250	Fixed/FC	31106
			31107




		3P	4P
E50986	Interpact INS320	Fixed/FC	31108
	Interpact INS400	Fixed/FC	31110
	Interpact INS500	Fixed/FC	31112
	Interpact INS630	Fixed/FC	31114
			31115

### Interpact INS250 to INS630 with red handle and yellow front




		3P	4P
E50985	Interpact INS250-100A	Fixed/FC	31120
	Interpact INS250-160A	Fixed/FC	31124
	Interpact INS250-200A	Fixed/FC	31122
	Interpact INS250	Fixed/FC	31126
			31127



		3P	4P
E50986	Interpact INS320	Fixed/FC	31128
	Interpact INS400	Fixed/FC	31130
	Interpact INS500	Fixed/FC	31132
	Interpact INS630	Fixed/FC	31134
			31135


### Source changeover systems

#### Complete assembly




		3P	4P
E42829	With Interpact INS250-100A	Fixed/FC	31140
	With Interpact INS250-160A	Fixed/FC	31144
	With Interpact INS250-200A	Fixed/FC	31142
	With Interpact INS250	Fixed/FC	31146
	With Interpact INS320	Fixed/FC	31148
	With Interpact INS400	Fixed/FC	31150
	With Interpact INS500	Fixed/FC	31152
	With Interpact INS630	Fixed/FC	31154
			31155

#### Interlocks



Mechanical for INS250	31073
Mechanical for INS320/400/630	31074
Keylock type (2 keylocks / 1 key) Ronis	41950
Profalux	42878
Locking device for Ronis/Profalux keylocks on INS250	31087 (x2)
Locking device for Ronis/Profalux keylocks on INS320/400/630	31088 (x2)

#### Downstream coupling accessories



	3P	4P
E50988	For Interpact INS250	29358
	Long terminal shields (1 pair)	29324
	For Interpact INS320/400/630	32619
	Long terminal shields (1 pair)	32620
		32565

### Individual enclosures

#### IP55 heavy-duty sheetmetal enclosure



For INS250 with standard extended rotary handle	31200
For INS250 with red extended rotary handle on yellow front	31201
For INS320/400/630 with standard extended rotary handle	31202
For INS320/400/630 with red extended rotary handle on yellow front	31203

#### IP55 insulating enclosure




For INS250 with standard extended rotary handle	31204
For INS250 with red extended rotary handle on yellow front	31205
For INS320/400/630 with standard extended rotary handle	31206
For INS320/400/630 with red extended rotary handle on yellow front	31207


# INV100 to 630 (visible break)

## Complete device

### Interpact INV100 to INV630 standard version




		3P	4P
Interpact INV100	Fixed/FC	31160	31161
Interpact INV160	Fixed/FC	31164	31165
Interpact INV200	Fixed/FC	31162	31163
Interpact INV250	Fixed/FC	31166	31167




		3P	4P
Interpact INV320	Fixed/FC	31168	31169
Interpact INV400	Fixed/FC	31170	31171
Interpact INV500	Fixed/FC	31172	31173
Interpact INV630	Fixed/FC	31174	31175

### Interpact INV100 to INV630 with red handle and yellow front



		3P	4P
Interpact INV100	Fixed/FC	31180	31181
Interpact INV160	Fixed/FC	31184	31185
Interpact INV200	Fixed/FC	31182	31183
Interpact INV250	Fixed/FC	31186	31187



		3P	4P
Interpact INV320	Fixed/FC	31188	31189
Interpact INV400	Fixed/FC	31190	31191
Interpact INV500	Fixed/FC	31192	31193
Interpact INV630	Fixed/FC	31194	31195

## Individual enclosures


### IP55 insulating enclosure



For INV100/160/250 with standard rotary handle	31204
For INV100/160/250 with red rotary handle on yellow front	31205
For INV320/400/630 with standard rotary handle	31206
For INV320/400/630 with red rotary handle on yellow	31207

## INV specific accessories


### Spare viewport



For INV100/160/250	31089
For INV320/400/630	31090



NV100/160/250 - NS250 combination assembly	31066
INV320/400/630 - NS250 combination assembly	31067
Front alignment base for INV320/400/630 - NS250 combination assembly	31064
INV320/400/630 - NS400/630 combination assembly	31068



Flexible connection assembly, vertical INV100/160/250 to horizontal NS250	31069
Flexible connection assembly, vertical INV320/400/630 to horizontal NS250	31092
Flexible connection assembly, vertical INV100/160/250 to vertical NS250, side-by-side	31071
Flexible connection assembly, vertical INV320/400/630 to vertical NS400/630, side-by-side	31072
Flexible connection assembly, vertical INV320/400/630 to vertical NS250, side-by-side	31093

# Accessories

## INS250

### INV100 to 250 (visible break)

#### Connection accessories (Cu or Al)

##### Rear connections




Short (1 pair)	29235
Long (1 pair)	29236

##### Bare cable connectors




Snap-on, for cables:	1.5 to 95 <sup>□</sup> ; ≤ 160 A	Set of 3	29242
	10 to 185 <sup>□</sup> ; ≤ 250 A	Set of 4	29243
Tab connector for voltage tap on 185 <sup>□</sup> bare cable connector		Set of 3	29259
Clip for bare cable connector		Set of 4	29260
Distribution connector for six 1.5 to 35 <sup>□</sup> cables with phase barriers		Set of 2	29348
		Set of 10	29241
		Set of 3	29248
		Set of 4	29249

##### "Polybloc" distribution block (for bare cables)



160 A (40°C), for 6 cables up to 10 <sup>□</sup>	7100
250 A (40°C), for 9 cables up to 10 <sup>□</sup>	7101

##### Terminal extensions (supplied with 2 or 3 phase barriers)



Right-angle terminal extensions	Set of 3	29261
	Set of 4	29262
Straight terminal extensions	Set of 3	29263
	Set of 4	29264

##### Spreaders (for upstream or downstream connection)



Separate for each pole	3P	31563
	4P	31564
One-piece	3/4P	31061
Front alignment base	3/4P	31064

##### Crimp lugs for copper cables (supplied with 2 or 3 phase barriers)



For cable 120 <sup>□</sup>	Set of 3	29252
	Set of 4	29256
For cable 150 <sup>□</sup>	Set of 3	29253
	Set of 4	29257
For cable 185 <sup>□</sup>	Set of 3	29254
	Set of 4	29258

##### Crimp lugs for aluminium cables (supplied with 2 or 3 phase barriers)



For cable 150 <sup>□</sup>	Set of 3	29504
	Set of 4	29505
For cable 185 <sup>□</sup>	Set of 3	29506
	Set of 4	29507

##### Terminal shields



Short (1 pair)	3/4 P	29322
Long (1 pair)	3/4 P	29324

## Electrical auxiliaries


### Auxiliary contacts (changeover type)



OF or CAM (early make or break)	29450
Low-level OF or CAM (early make or break)	29452


## Indication and measurement modules

### Ammeter module (4P)



Adaptation kit (necessary for devices with direct front handles)	31081
Rating (A)	
100	29456
150	30556
250	31566


### Current transformer module (4P)



Rating (A)	100	29458
	150	30558
	250	31568

## Rotary handles

### Extended front handles



For INS250 with standard handle	31050
For INS250 with red handle on yellow front	31051


### Lateral handles



Direct handle conversion accessory (to be combined with extended lateral handle)	31054
For INS and INV250 with standard handle	31057
For INS and INV250 with red handle on yellow front	31058


## Locks, interlocks and coupling accessories

### Locks




By 1 to 3 padlocks (OFF position)	built-in
Locking device for Ronis/Profalux keylocks (without keylocks)	31087
Keylock	
Ronis 1351B.500	41940
Profalux KS5 B24 D4Z	42888

### Interlocks



Mechanical for INS250	31073
Keylock type (2 keylocks / 1 key)	41950
Locking device for Ronis/Profalux keylocks	42878


### Coupling accessories



Downstream coupling for Interpact INS250	3P	29358
Downstream coupling for Interpact INS250	4P	29359
Long terminal shields (1 pair)		29324

## Installation accessories

### Front panel escutcheons



For switch-disconnector	31079
For ammeter module, IP40	29318

### Lead seal accessories

29375

### Spare parts

12 snap-in nuts for fixed/FC (M8)	30554
100 identification labels	29314
Bag of screws	29312
Black handle	31082
Red handle	31083
Viewport for INV100/160/250	31089

### Connection accessories (Cu or Al)

#### Rear connections



Short (1 pair)	32475
Long (1 pair)	32476

#### Bare cable connectors




For 1 cable, 35 <sup>2</sup> to 300 <sup>2</sup>	Set of 3	32479
	Set of 4	32480
For 2 cables, 35 <sup>2</sup> to 240 <sup>2</sup>	Set of 3	32481
	Set of 4	32482
Tab connector for voltage tap on 185 <sup>2</sup> bare cable connector	Set of 2	29348

#### Terminal extensions (supplied with 2 or 3 phase barriers)



Right-angle terminal extensions	Set of 3	32484
	Set of 4	32485
Edgewise terminal extensions	Set of 3	32486
	Set of 4	32487

#### Spreaders (for upstream or downstream connection)



Separate for each pole	52.5 mm	3P	32490
	70 mm	4P	32491
		3P	32492
		4P	32493
One-piece		3/4P	(1)
Front alignment base		3/4P	(1)

#### Crimp lugs for copper cables (supplied with 2 or 3 phase barriers)



For 240 <sup>2</sup> cables	Set of 3	32500
	Set of 4	32501
For 300 <sup>2</sup> câbles	Set of 3	32502
	Set of 4	32503

#### Crimp lugs for aluminium cables (supplied with 2 or 3 phase barriers)



For 240 <sup>2</sup> cables	Set of 3	32504
	Set of 4	32505
For 300 <sup>2</sup> câbles	Set of 3	32506
	Set of 4	32507

#### Terminal shields



Short (1 pair)	3/4 P	32563
Long (1 pair)	3/4 P	32565
Longs for spreader (1 pair supplied with insulating plate)	3/4P	32583

(1) Available soon

## Electrical auxiliaries

### Auxiliary contacts (changeover type)


E 8908	OF or CAM (early make or break)	29450
	Low-level OF or CAM (early make or break)	29452



## Indication and measurement modules


### Ammeter module (4P)

E 8908	Rating (A)	400	32656
		600	32856



### Current transformer module (4P)

E 8909	Rating (A)	400	32658
		600	32858



## Rotary handles

### Extended front handles

E 8910	For INS320/400/630 with standard handle	31052
	For INS320/400/630 with red handle on yellow front	31053



## Locks, interlocks and coupling accessories

### Locks

E 8912	By 1 to 3 padlocks on handle (open position)	built-in
	Locking device for Ronis / Profalux keylocks (without keylock)	31088
	Keylock	Ronis 1351B.500 Profalux KS5 B24 D4Z 41940 42888

### Interlocks

E 8987	Mechanical for INS320/400/630	31074
	Keylock type (2 keylocks / 1 key)	Ronis 1351B.500 Profalux KS5 B24 D4Z 41950 42878
	Locking device for Ronis / Profalux keylocks	31088 (x2)

### Coupling accessories

E 8988	Downstream coupling for Interpact INS320/400/630	4P	32619
	Downstream coupling for Interpact INS320/400/630	3P	32620
	Long terminal shields with 52.5 mm pitch (1 pair)		32583

## Installation accessories

### Front panel escutcheons

E 8989	For switch-disconnector	31080
	For ammeter module, IP40	29318

### Lead seal accessories



		29375
--	--	-------

## Spare parts

100 identification labels	29314
Bag of screws	32552
Black handle	31084
Red handle	31085
Viewport for INV320/400/630	31090

## Complete device

### Interpact IN1000 to IN2500



		3P	4P
Interpact IN1000	Fixed/FC	<b>47775</b>	<b>47751</b>
Interpact IN1600	Fixed/FC	<b>47776</b>	<b>47851</b>
Interpact IN2500	Fixed/FC	<b>47777</b>	<b>47855</b>

## Accessories

### Locks and interlocks


#### Handle locking

E24074 	By 3 padlocks	built-in
	By keylock (in OFF or ON position)	
	1 keylock	Ronis 135.500 Profalux KS5B24D4Z

#### ON position door interlock (for devices with extended rotary handles)

47754

#### Key type interlock

E24024/1 	2 keylocks / 1 key	Ronis 1351.500 Profalux KS5B24D4Z	41950 42878

### Spare parts

#### Black handle for direct rotary control


E24083 	IN1000/IN1600	47759
	IN2500	47862

### Connection accessories (Cu or Al)

#### Terminal extensions for bars

E24080/1 	Edgewise terminal extensions	IN1000 (per pole) IN1600 (per pole)	47758 47858

#### Spreaders (for upstream or downstream connection)

E24081  E24092/3 	IN1000	set of 3 set of 4	47760 47761
	IN1600	set of 3 set of 4	47760 47761
	IN2500		1 set supplied

#### Connectors


E24036 	IN2500 (1 connector)	55675

#### Phase barriers

E24026 	IN1000/IN1600	3P/4P	47756
	IN2500	3P/4P	47860

### Electrical auxiliaries

#### Auxiliary contacts

E24072 	1 OF or CAM (depending on how it is mounted)	42906
	2 OF contacts	47757

### Rotary handles

#### Accessories for conversion to extended rotary handle (short shaft)

E23946 	Front handle	47753

## *Notes*

---



## *Notes*

---

**Schneider Electric SA**

5, rue Nadar  
92506 Rueil-Malmaison Cedex  
France

Tel: +33 (0)1 41 29 82 00  
Fax:+33 (0)1 47 51 80 20

<http://www.schneiderelectric.com>

As standards, specifications and designs change from time to time, please ask for confirmation of the information given in this publication.

 This document has been printed on ecological paper.

Design: Schneider  
Photo: Schneider  
Printed: imprimerie des Deux-Ponts