Midi free-standing Beacons / LED Rotating Beacon 829 LED Rotat. Beacon RM 115-230VAC BU

Part No.: 829.517.68



i

MECHANICAL DATA		
Height	200 mm	
Diameter	98 mm	
Materials	PC PC/ABS	
Dome colour	Blue	
Housing colour	Black	
Protection category	IP65	
Connection	Screw terminals	
cross-sectional area minimum	0,50mm² / 20AWG	
cross-sectional area maximun	n 1,50mm² / 16AWG	
Cable entry	Rubber pinch	
Cable entry minimum	d = 5 mm	
Cable entry maximum	d = 7 mm	
Type of fixing	Tube mounting	
Working temperature minimur		
Working temperature maximu		
Weight with packaging	342 g	
Product weight	275 g	
ELECTRICAL DATA		
Operating voltage	115-230V	
Operating voltage type	AC	
Operating voltage frequency	50Hz at 230V 60Hz at 115V	
Operating voltage tolerance	+/- 10%	
Rated operational voltage	230 VAC	
Rated operational current	300 mA	
Rated inrush current	500 mA	
Protection class	Protection class 2	
Pollution degree	3	
Overvoltage category	II	
Isolation voltage	Ui = 250V; Uimp = 2.500V	
OPTICAL DATA		
Light source	LED	
Light colour	Blue	
Optical signal image	Revolving	
Service life optical	50,000 h maximum	

For additional installation and mounting information, refer to the appropriate user guide at www.werma.com. This printed copy is for information only and is subject to alteration.

ļ


Midi free-standing Beacons / LED Rotating Beacon 829 LED Rotat. Beacon RM 115-230VAC BU

APPROVAL DATA	
Conforms with CE	Yes
WEEE	Yes
Conforms with ATEX-directive	No
Conforms with CCC	Yes
Conforms with UL	cULus
UL Type Rating	Type 12
Conforms with FCC	No
Conforms with IC	No
EAC certificate available	Yes
Conforms with AS-I	No
ICAO Certification	No
Conforms with DNV	No
Conforms with RoHS CN	No
Conforms with VdS	No

For additional installation and mounting information, refer to the appropriate user guide at www.werma.com. This printed copy is for information only and is subject to alteration.

i

Midi free-standing Beacons / LED Rotating Beacon 829 LED Rotat. Beacon RM 115-230VAC BU



For additional installation and mounting information, refer to the appropriate user guide at www.werma.com. This printed copy is for information only and is subject to alteration.