



97100 Inline, 3/2 & 5/2 Indirect solenoid actuated spool valves



- > Port size: 1/4" (ISO G/NPT)
- > For single and double operated actuators
- > Crossover-free switching, switch-over function guaranteed even with small cross section air supply
- > Manual override with detent standard

- > The solenoid valves are applicable in the protection class
- > Ex m for zones 1, 2, 21, 22 (gases and dusts) ATEX cat.II 2GD
- > Ex ia for zones 1, 21, (gases) ATEX cat.II 2G,
- > Ex nA, for zones 2, 22 (gases and dusts) ATEX cat.II 3 GD



Technical features

Medium:

Filtered, non-lubricated or dry compressed air

Operation:

Indirectly solenoid operated soft seal valves

Operating pressure:

2 ... 8 bar (29 ... 116 psi)

Orifice:

6 mm

Port size:

G1/4, 1/4 NPT

Mounting position: Optional

Flow direction:

Fixed

Electrical connection:

See solenoid table

Ambient/Media temperature:

-15° ... +60°C (+5° ... +140°F) Depending on solenoid system Air supply must be dry enough to avoid ice formation at temperatures below +2°C (+35°F).

Materials:

Housing: Aluminium 3.0615 anodized

Pilot flange: Plastic (PBT)

Seals: NBR

Technical data

Symbol	Port size	Function	Actuation/return	Operating pressure (bar)	Flow (I/min)	Weight (kg)	Dimension No.	Model *1)
122 10	G 1/4	3/2	Solenoid/air spring	2 8	750	0,25	1	9713032
	1/4 NPT	3/2	Solenoid/air spring	2 8	750	0,25	1	9713042
1 3								
14 4 2 12	G 1/4	5/2	Solenoid/air spring	2 8	750	0,25	2	9710032
	1/4 NPT	5/2	Solenoid/air spring	2 8	750	0,25	2	9710042
513								
14 4 2 12	G 1/4	5/2	Solenoid/Solenoid	2 8	750	0,35	3	9711032
	1/4 NPT	5/2	Solenoid/Solenoid	2 8	750	0,35	3	9711042
513								
14 4 2 12	G 1/4	5/3 APB	Solenoid/Solenoid, APB	28	500	0,40	4	9712032
	1/4 NPT	5/3 APB	Solenoid/Solenoid, APB	2 8	500	0,40	4	9712042
513								

^{*1)} When ordering, please indicate solenoid, voltage and current (frequency). Valve function: APB = All Ports Blocked







Solenoids, standard voltages

	Power consumption 24 V d.c. 230 V a.c.				Protection Ex-Protection class (ATEX-Cate-IP/NEMA gory)		Temperature Ambient/ Media	Electrical connection	Weight	Drawing	Circuit diagram	Model
		(VA)		(m A)	IF/ NEIVIA	gory)	(°C)		(kg)	No.	No.	
Signal Control	1,8	-	70	-	IP65 (with connector)	_	-15 +50	Connector DIN EN 175301-803, form B *1)	0,1	11	1	3050
(A)	0,7	2,0 *2)	29	4	IP65 (with connector)	_	-15 +50	Connector DIN EN 175301-803, form A *1)	0,1	12	1	3034
0	2	_	85	_	IP65 (with connector)	II 3 G Ex nA IIC T5 Gc II 3 D Ex tc IIIC T95° Dc IP65	-15 +50	Special connector DIN EN 175301-803, form A	0,3	12	1	3046
	2,7	-	115	-	IP65 (with connector)	II 2 G Ex mb IIC T5 Gb II 2 D Ex mb tb T95°C Db	-20 +50 *2)	Cable length 3 m	0,3	13	14	3062
	_	2,1	_	9	IP65 (with connector)	II 2 G Ex mb IIC T5 Gb II 2 D Ex mb tb T95°C Db	-20 +50 *2)	Cable length 3 m	0,3	13	15	3063
(2) (1) (1) (1) (1) (1) (1) (1) (1) (1) (1	2,7	_	115	_	IP66 (with connector)	_	-10 +50	Connector *1) M12x1, DIN IEC 61076-2-101 Solenoid with yellow LED	0,1	14	17	3071

 $Standard\ voltages\ (\pm 10\%)\ 24\ V\ d.c.,\ 230\ V\ a.c.,\ other\ voltages\ on\ request.\ Design\ according\ to\ VDE\ 0580,\ EN\ 50014/50028.\ 100\%\ duty\ cycle.$

Solenoid actuators for intrinsically-safe circuits

Nominal resistance RN coil (Ω)	Min. required switching current (mA)	Resistance Rw 60 coil (Ω)	Required voltage at terminal Rw 60 (V)	IP Protection class	Ex-Protection (ATEX-Cate- gory)	Temperature Ambient/ Media (°C)	Weight (kg)	Drawing No.	Circuit diagram No.	Model
275	37	345	13,8	IP65 (with connector)	II 2 G Ex ia IIC T6/ T4 Ga	T6: -40 +50 T4: -40 85	0,2	15	13	3039

When selecting an intrinsically safe power supply, the permissible maximum values according to the Certificate of Conformity should be taken in account. On the other hand, the low effective inductivity and capacity can be ignored.

Connector DIN EN 175301-803 form A is not scope of delivery, see table »Accessories»

Approvals

Model	Approvals ATEX	IECEx	FM	Datasheet
3039	PTB 03 ATEX 2134	_	CSA-LR 51090-4	N/en 7.1.550
304x	PTB 06 ATEX 2055	_	_	N/en 7.1.555
306x	PTB 03 ATEX 2015	_	_	N/en 7.1.560
307x	EC-Declaration of Conformity	_	_	N/en 7.1.565

^{*1)} Connector is not scope of delivery, see table »Accessories«


^{*2)} For battery installation +40°C only












Accessories



Manifold plates



Accessories for manifold plates



^{*1)} For blocking of unused valve stations

^{*2)} Necessory for using two different pressure








Dimensions

Valves


























[■] Solenoid 90° turnable

² Manual override

³ Port size G1/4 or 1/4 NPT









Dimensions in mm Projection/First angle


Dimensions

Manifold plate 2 and 3 stations




Manifold plate 4 ... 12 stations






Model	Α	В	С	D	Е	F	G	Н	J	K	L	M	N	0	Р	R	S	Т	U
2er	52	104	26	9	8	13	20	33	10	35,5	52	G 1/8	G 3/8	40	24	26	-	26	for M5
3er	52	104	26	9	8	13	20	33	10	35,5	78	G 1/8	G 3/8	40	24	52	-	26	for M5
4-12er	52	104	26	9	8	13	20	33	10	35,5	(x·26)+23	G 1/8	G 3/8	40	24	6,5	(x·26)+10	26	for M5





Dimensions































Electrical connection M 12 x 1









Pin	Signal	Cable
1	+ UB	brown
2	Out 2 (PNP) / analogue 4 to 20 mA	white
3	O Volt	blue
4	Out 1 (PNP)	black

 $\fbox{1}$ Connector $4 \times 90^\circ$ turnable



Incorporating




Dimensions in mm


Circuit diagrams
















Silencer Model: M/S2, C/S2



Warning

These products are intended for use in industrial compressed air systems only. Do not use these products where pressures and temperatures can exceed those listed under **»Technical features/**

Before using these products with fluids other than those specified, for non-industrial applications, life-support systems or other applications not within published specifications, consult Norgren.

Through misuse, age, or malfunction, components used in fluid power systems can fail in various modes.

The system designer is warned to consider the failure modes of all component parts used in fluid power systems and to provide adequate safeguards to prevent personal injury or damage to equipment in the event of such failure.

System designers must provide a warning to end users in the system instructional manual if protection against a failure mode cannot be adequately provided.

System designers and end users are cautioned to review specific warnings found in instruction sheets packed and shipped with these products.